







Align the aluminum logo cap to the desired angle of rotation, and press it onto the back of the enclosure. Apply masking tape (not included) to hold the cap in place until the silicone cures (at least 24 hours).



- For marine installations, do not connect the speaker's LED lights to the vessel's navigational lighting circuits.
- For short-circuit protection, install a supplied fuseholder onto EACH speaker's BLUE (+12V) LED power connection lead.
- Connect all BLUE (+12V) leads together (parallel) and connect to a switched +12V supply. Connect all YELLOW (GND) leads together and connect to a negative ground or to the NEGATIVE battery post.
- We recommend activating the speakers' LEDs thru a lighting circuit that supplies +12V via an existing switch. If an existing switched circuit is not available, you may install a dedicated toggle/rockert style switch that will supply positive (+12V) power. Fuse this connection according to how many LED circuits you have [LED circuits x 150 mA].



Clean the inside of the aluminum cap with acetone (not included) prior to attaching it to the enclosure. Apply a circular head of silicone adhesive to the inside of the aluminum logo cap. 1/2-inch (13 mm) from the outer edge.



Example: One speaker pair of LED circuits connected in parallel.



Rotate the speaker to the desired angle. Reinstall the speaker and speaker mounting screws and washers. Hand-tighten in a criss-cross pattern.



Gently press on the applique from the center out to remove any air pockets.




If you wish to rotate the speaker's grille/logo badge alignment, remove the six #8 x 1-1/4" speaker mounting screws and #8 Flat Washers.



Remove the backing from the rear logo applique. With the logo positioned at the desired angle, attach the applique to the back of the enclosure.



Apply Loctite® red thread-locking compound to two M6 x 16 mm Machine Screws, slide them through the slots in the clamp receiver, into the appropriate holes in the fixture base, and fully tighten.



Realign the clamps with the clamp receiver on the enclosure, and secure them to the clamp receiver using a pair of M6 x 16 mm Machine Screws, M6 Flat Washers, and M6 Locknuts as illustrated. The locknut should be installed into the hex shaped recess on one end of each clamp. The locknut should be installed into the hex shaped recess on one end of each clamp.



Place the supplied plastic strip around the pipe to prevent scratching. Push the clamps over the pipe (remove the plastic strip). Align the clamps with the clamp receiver on the enclosure.



Position the enclosure at the desired location, tightening the M6 x 45 mm Machine Screws as necessary. Fully tighten the pre-installed M4 x 4 mm Set Screw in the clamp receiver to hold its position. Mark the location of the clamps on the pipe, then remove the enclosure from the pipe.



Loosen the pre-installed M4 x 4 mm Set Screw in the clamp receiver. Slide an M6 x 16 mm Machine Screw through the center hole of the clamp receiver, into the center hole in the fixture base, and hand tighten.



Secure the clamps to the clamp receiver using a pair of M6 x 16 mm Machine Screws, M6 Flat Washers, and M6 Locknuts as illustrated. The locknut should be installed into the hex shaped recess on one end of each clamp. Hand-tighten, allowing just enough freedom to rotate the enclosure around the pipe.