

GARMIN[®]

eTrex[®] Touch 25/35



Owner's Manual

All rights reserved. Under the copyright laws, this manual may not be copied, in whole or in part, without the written consent of Garmin. Garmin reserves the right to change or improve its products and to make changes in the content of this manual without obligation to notify any person or organization of such changes or improvements. Go to www.garmin.com for current updates and supplemental information concerning the use of this product.

Garmin®, the Garmin logo, Auto Lap®, BlueChart®, City Navigator®, eTrex®, and TracBack® are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. ANT+®, BaseCamp™, chirp™, Garmin Connect™, Garmin Express™, HomePort™, tempe™, VIRB®, and GSC™ are trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Garmin is under license. Mac® is a registered trademark of Apple Computer, Inc. Windows® is a registered trademark of Microsoft Corporation in the United States and other countries. microSD™ and the microSDHC logo are trademarks of SD-3C, LLC. Other trademarks and trade names are those of their respective owners.

NMEA® is a registered trademark of the National Marine Electronics Association. NMEA 2000® and the NMEA 2000 logo are registered trademarks of the National Marine Electronics Association.

This product is ANT+® certified. Go to www.thisisant.com/directory for a list of compatible products and apps.

Table of Contents

Introduction	1	Downloading Geocaches.....	5
Device Overview.....	1	Filtering the Geocache List.....	5
Installing AA Batteries.....	1	Creating and Saving a Geocache Filter.....	5
Battery Information.....	1	Editing a Custom Geocache Filter.....	5
Turning On the Device.....	1	Navigating to a Geocache.....	5
Using the Touchscreen.....	1	chirp™.....	6
Home Screen.....	1	Enabling chirp Searching.....	6
Using the Power Key Menu	1	Finding a Geocache with a chirp.....	6
Tracks	1	Logging the Attempt.....	6
Recording a Track Log.....	1	Applications	6
Customizing Your Track Log.....	1	Sending and Receiving Data Wirelessly.....	6
Navigating Using TracBack®.....	2	Setting a Proximity Alarm.....	6
Saving the Current Track.....	2	Calculating the Size of an Area.....	6
Viewing Track Information.....	2	Viewing the Calendar and Almanacs.....	6
Viewing the Elevation Plot of a Track.....	2	Setting an Alarm.....	6
Saving a Location on a Track.....	2	Starting the Countdown Timer.....	6
Changing the Track Color.....	2	Opening the Stopwatch.....	6
Archiving Tracks Automatically.....	2	Satellite Page.....	6
Clearing the Current Track.....	2	Changing the Satellite View.....	6
Deleting a Track.....	2	Turning Off GPS.....	6
Waypoints	2	Simulating a Location.....	6
Creating a Waypoint.....	2	Controlling a VIRB® Action Camera.....	7
Finding a Waypoint.....	2	Phone Notifications.....	7
Editing a Waypoint.....	2	Pairing a Smartphone with Your Device.....	7
Deleting a Waypoint.....	3	Hiding Notifications.....	7
Increasing the Accuracy of a Waypoint Location.....	3	Fitness	7
Projecting a Waypoint.....	3	Running or Cycling with Your Device.....	7
Routes	3	History.....	7
Creating a Route.....	3	Viewing an Activity.....	7
Editing the Name of a Route.....	3	Deleting an Activity.....	7
Editing a Route.....	3	Using Garmin Connect.....	7
Viewing a Route on the Map.....	3	Optional Fitness Accessories.....	7
Deleting a Route.....	3	About Heart Rate Zones.....	8
Viewing the Active Route.....	3	Fitness Goals.....	8
Reversing a Route.....	3	Setting Your Heart Rate Zones.....	8
Garmin® Adventures	3	Customizing the Device	8
Sending Files to BaseCamp.....	3	Adjusting the Backlight Brightness.....	8
Creating an Adventure.....	3	Locking the Touchscreen.....	8
Starting an Adventure.....	4	Unlocking the Touchscreen.....	8
Where To? Menu	4	Setting the Touchscreen Sensitivity.....	8
Optional Maps.....	4	Display Settings.....	8
Finding a Location Near Another Location.....	4	Configuring the Maps.....	8
Finding an Address.....	4	General Map Settings.....	8
Navigation	4	Advanced Map Settings.....	8
Navigating to a Destination.....	4	Custom Data Fields and Dashboards.....	8
Stopping Navigation.....	4	Enabling the Map Data Fields.....	8
Acquiring Satellite Signals.....	4	Customizing the Data Fields.....	8
Navigating with the Map.....	4	Customizing Dashboards.....	9
Navigating a Driving Route.....	4	Profiles.....	9
Navigating with the Compass.....	4	Selecting a Profile.....	9
Calibrating the Compass.....	4	Creating a Custom Profile.....	9
Course Pointer.....	5	Editing a Profile Name.....	9
Marking and Starting Navigation to a Man Overboard		Deleting a Profile.....	9
Location.....	5	System Settings.....	9
Navigating with Sight 'N Go.....	5	GPS and GLONASS.....	9
Elevation Plot.....	5	Display Settings.....	9
Navigating to a Point on the Plot.....	5	Appearance Settings.....	9
Changing the Plot Type.....	5	Setting the Device Tones.....	9
Resetting the Elevation Plot.....	5	Tracks Settings.....	9
Calibrating the Barometric Altimeter.....	5	Routing Settings.....	9
Geocaches	5	Heading Settings.....	9
		Altimeter Settings.....	10
		Position Format Settings.....	10
		Changing the Units of Measure.....	10
		Time Settings.....	10

Geocaching Settings	10
ANT+ Sensor Settings	10
Fitness Settings	10
Setting Your Fitness User Profile	10
Marking Laps by Distance	10
Marine Settings	10
Setting Up Marine Alarms	10
Resetting Data	11
Restoring Default Values for Specific Settings	11
Restoring Default Values for Specific Page Settings	11
Restoring All Default Settings	11
Device Information	11
Specifications	11
Support and Updates	11
Setting Up Garmin Express	11
Getting More Information	11
Registering Your Device	11
Battery Information	11
Maximizing the Battery Life	11
Turning On Battery Save Mode	11
Long-Term Storage	11
Device Care	11
Cleaning the Device	11
Cleaning the Touchscreen	12
Water Immersion	12
Data Management	12
File Types	12
Installing a Memory Card	12
Connecting the Device to Your Computer	12
Transferring Files to Your Device	12
Deleting Files	12
Disconnecting the USB Cable	12
Troubleshooting	12
Resetting the Device	12
Viewing Device Information	12
Appendix	13
tempe	13
Data Fields	13
Heart Rate Zone Calculations	14
Index	15

Introduction

⚠ WARNING

See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

Device Overview



①	Power key
②	Mini-USB port (under weather cap)
③	Battery cover D-ring
④	microSD™ card slot (under battery door)

Installing AA Batteries

The handheld device operates on two AA batteries (not included). Use NiMH or lithium batteries for best results.

- 1 Turn the D-ring counter-clockwise, and pull up to remove the cover.
- 2 Insert two AA batteries, observing polarity.



- 3 Replace the battery cover, and turn the D-ring clockwise.

Battery Information

⚠ WARNING

The temperature rating for the device may exceed the usable range of some batteries. Alkaline batteries can rupture at high temperatures.

Do not use a sharp object to remove batteries.

⚠ CAUTION

Contact your local waste disposal department to properly recycle the batteries.

NOTICE

Alkaline batteries lose a significant amount of their capacity as the temperature decreases. Use lithium batteries when operating the device in below freezing conditions.

Turning On the Device

Hold

Using the Touchscreen

- Tap the screen to select an item.
- Make each touchscreen selection a separate action.
- Select to save your changes and close the page.
- Select to return to the previous page.
- Select to return to the main menu.
- Select to view specific menu items for the page you are viewing.

Home Screen



①	Activity
②	Where To?
③	Activity settings

Using the Power Key Menu

Before you can use certain features, you may need to select the power key.

You can access many features, such as Track Manager, Waypoint Manager, and geocaching, from the power key menu.

From any screen, select , and select a feature.

Tracks

A track is a recording of your path. The track log contains information about points along the recorded path, including time, location, and elevation for each point.


Recording a Track Log


- 1 Select an activity.
- 2 After the GPS indicator bars turn green, select **Start**.
- 3 After your activity, swipe up from the bottom of the screen.
- 4 Select **Stop**.
The data summary page appears.
- 5 Scroll vertically to see all the data (optional).
TIP: You can select the name of the track to change it.
- 6 Select an option:
 - To save the track, select .
 - To discard the track, select .

Customizing Your Track Log

You can customize how your device displays and records tracks.


- 1 Select **Current Track** >

- 2 Select an option:
 - To change the color of the track line on the map, select **Color**.
 - To display a line on the map indicating your track, select **Show On Map**.
- 3 Select  > **Setup Tracks** > **Record Method**.
- 4 Select an option:
 - To record tracks at a variable rate that creates an optimum representation of your tracks, select **Auto**.
 - To record tracks at a specified distance, select **Distance**.
 - To record tracks at a specified time, select **Time**.
- 5 Select **Interval**.
- 6 Complete an action:
 - If you selected **Auto** for the **Record Method**, select an option to record tracks more or less often.



NOTE: Using the **Most Often** interval provides the most track detail, but fills up the device memory quicker.
 - If you selected **Distance** or **Time** for the **Record Method**, enter a value, and select .

Navigating Using TracBack®


While navigating, you can navigate back to the beginning of your track. This can be helpful when finding your way back to camp or the trail head.

- 1 Select **Current Track** >  > **TracBack**.
The map displays your route with a magenta line, start point, and end point.
- 2 Navigate using the map or the compass.


Saving the Current Track

- 1 Select **Track Manager** > **Current Track**.
- 2 Select an option:
 - Select  to save the entire track.
 - Select  > **Save Portion**, and select a portion.



Viewing Track Information

- 1 Select **Track Manager**.
- 2 Select a track.
- 3 Select .
The beginning and the end of the track are marked by flags.
- 4 Select the information bar at the top of the screen.
Information about the track appears.

Viewing the Elevation Plot of a Track

- 1 Select **Track Manager**.
- 2 Select a track.
- 3 Select .

Saving a Location on a Track

- 1 Select **Track Manager**.
- 2 Select a track.
- 3 Select .
- 4 Select a location on the track.
- 5 Select the information bar at the top of the screen.
Information about the location appears.
- 6 Select  > **OK**.

Changing the Track Color

You can change the color of a track to improve the view on the map or compare it to another track.


- 1 Select **Track Manager**.
- 2 Select a track.
- 3 Select **Color**.
- 4 Select a color.

Archiving Tracks Automatically

You can archive tracks on an automated schedule to save memory space.

- 1 Select **Setup** > **Tracks** > **Advanced Setup** > **Auto Archive**.
- 2 Select **When Full**, **Daily**, or **Weekly**.

Clearing the Current Track

- 1 From the current track screen, swipe up from the bottom of the screen.
- 2 Select **Stop** >  > **Clear**.

Deleting a Track



- 1 Select **Track Manager**.
- 2 Select a track.
- 3 Select  > **Delete**.

Waypoints


Waypoints are locations you record and store in the device. Waypoints can mark where you are, where you are going, or where you have been. You can add details about the location, such as name, elevation, and depth.

Creating a Waypoint

You can save a location as a waypoint.


- 1 Select an activity.
- 2 Select .
- 3 Tap a location on the map.
- 4 Select the information text box.
The review page appears.
- 5 Select .
The waypoint saves automatically.
- 6 Select **OK**.

Finding a Waypoint


- 1 Select **Waypoint Manager**.
- 2 Select a waypoint from the list.
- 3 If necessary, select  to narrow the search.
- 4 Select an option:
 - Select **Spell Search** to search using the name of the waypoint.
 - Select **Select Symbol** to search using the symbol of the waypoint.
 - Select **Search Near** to search near a recently found location, another waypoint, your current location, or a point on the map.
 - Select **Sort** to view the list of waypoints based on nearest distance or alphabetical order.

Editing a Waypoint

Before you can edit a waypoint, you must create a waypoint.


- 1 Select **Waypoint Manager**.
- 2 Select a waypoint.
- 3 Select an item to edit, such as the name.
- 4 Enter the new information, and select .

Deleting a Waypoint

- 1 Select **Waypoint Manager** >  > **Delete**.
- 2 Select a waypoint.
- 3 Select **Delete** > **Yes**.

Increasing the Accuracy of a Waypoint Location




You can refine a waypoint location for more accuracy. When averaging, the device takes several readings at the same location and uses the average value to provide more accuracy.

- 1 Select **Waypoint Manager**.
- 2 Select a waypoint.
- 3 Select  > **Average Location**.
- 4 Move to the waypoint location.
- 5 Select **Start**.
- 6 Follow the on-screen instructions.
- 7 When the confidence status bar reaches 100%, select **Save**.

For best results, collect 4 to 8 samples for the waypoint, waiting at least 90 minutes between samples.

Projecting a Waypoint


You can create a new location by projecting the distance and bearing from a marked location to a new location.

- 1 Select **Waypoint Manager**.
- 2 Select a waypoint.
- 3 Select  > **Project Waypoint**.
- 4 Enter the bearing, and select .
- 5 Select a unit of measure.
- 6 Enter the distance, and select .
- 7 Select **Save**.

Routes

A route is a sequence of waypoints or locations that leads you to your final destination.

Creating a Route


- 1 Select **Route Planner** > **Create Route** > **Select First Point**.
- 2 Select a category.
- 3 Select the first point in the route.
- 4 Select **Use**.
- 5 Select **Select Next Point** to add additional points to the route.
- 6 Select  to save the route.

Editing the Name of a Route

- 1 Select **Route Planner**.
- 2 Select a route.
- 3 Select **Change Name**.
- 4 Enter the new name.

Editing a Route

- 1 Select **Route Planner**.
- 2 Select a route.
- 3 Select **Edit Route**.
- 4 Select a point.
- 5 Select an option:
 - To view the point on the map, select **Review**.

- To change the order of the points on the route, select **Move Up** or **Move Down**.
 - To insert an additional point on the route, select **Insert**. The additional point is inserted before the point you are editing.
 - To remove the point from the route, select **Remove**.
- 6 Select  to save the route.

Viewing a Route on the Map

- 1 Select **Route Planner**.
- 2 Select a route.
- 3 Select **View Map**.

Deleting a Route

- 1 Select **Route Planner**.
- 2 Select a route.
- 3 Select **Delete Route**.

Viewing the Active Route

- 1 While navigating a route, select **Active Route**.
- 2 Select a point in the route to view additional details.

Reversing a Route

You can switch the start and end points of your route to navigate the route in reverse.

- 1 Select **Route Planner**.
- 2 Select a route.
- 3 Select **Reverse Route**.

Garmin® Adventures

You can create adventures to share your journeys with family, friends, and the Garmin community. You can group related items together as an adventure. For example, you can create an adventure for your latest hiking trip. The adventure could contain the track log of the trip, photos of the trip, and geocaches you hunted. You can use BaseCamp™ to create and manage your adventures. For more information, go to adventures.garmin.com.

NOTE: BaseCamp is not available for all device models.

Sending Files to BaseCamp

- 1 Open BaseCamp.
- 2 Connect the device to your computer.

On Windows® computers, the device appears as a removable drive or a portable device, and the memory card may appear as a second removable drive. On Mac® computers, the device and memory card appear as mounted volumes.

NOTE: Some computers with multiple network drives may not display device drives properly. See your operating system documentation to learn how to map the drive.

- 3 Open the **Garmin** or memory card drive or volume.
- 4 Select an option:
 - Select an item from a connected device and drag it to My Collection or to a list.
 - From BaseCamp, select **Device** > **Receive from Device**, and select the device.

Creating an Adventure

Before you can create an adventure and send it to your device, you must download BaseCamp to your computer and transfer a track from your device to your computer ([Sending Files to BaseCamp](#), page 3).

- 1 Open BaseCamp.
- 2 Select **File > New > Garmin Adventure**.
- 3 Select a track, and select **Next**.
- 4 If necessary, add items from BaseCamp.
- 5 Complete the required fields to name and describe the adventure.
- 6 If you want to change the cover photo for the adventure, select **Change**, and select a different photo.
- 7 Select **Finish**.

Starting an Adventure

Before you can start an adventure, you must send an adventure from BaseCamp to your device ([Sending Files to BaseCamp, page 3](#)).

- 1 Select **Adventures**.
- 2 Select an adventure.
- 3 Select **Start**.

Where To? Menu

You can use the Where To? menu to find a destination to navigate to. Not all Where To? categories are available in all areas and maps.

Optional Maps

You can use additional maps with the device, such as BirdsEye satellite imagery, BlueChart® g2, and City Navigator® detailed maps. Detailed maps may contain additional points of interest, such as restaurants or marine services. For more information, go to <http://buy.garmin.com> or contact your Garmin dealer.

Finding a Location Near Another Location

- 1 From an activity screen, select **Q > ≡ > Search Near**.
- 2 Select an option.
- 3 Select a location.

Finding an Address

You can use optional City Navigator maps to search for addresses.

- 1 Select **Where To? > Addresses**.
- 2 Select the country or state, if necessary.
- 3 Enter the city or postal code.
NOTE: Not all map data provides postal code searching.
- 4 Select the city.
- 5 Enter the house number.
- 6 Enter the street.

Navigation

You can navigate routes and tracks, to a waypoint, geocache, photo, or any saved location in the device. You can use the map or the compass to navigate to your destination.

Navigating to a Destination

- 1 From an activity screen, select **Q**.
- 2 Select a category.
- 3 Select a destination.
- 4 Select **Go**.
The map opens and your route is marked with a magenta line.

- 5 Navigate using the map ([Navigating with the Map, page 4](#)) or compass ([Navigating with the Compass, page 4](#)).

Stopping Navigation

- 1 From the map or compass, swipe up from the bottom of the screen.
- 2 Select **Stop**.

Acquiring Satellite Signals

Before you can use the GPS navigation features, such as recording a track, you must acquire satellite signals. The device may need a clear view of the sky to acquire satellite signals. It may take 30 to 60 seconds to acquire satellite signals.

- 1 Hold **⏻**.
- 2 Select an activity.
- 3 Wait until the GPS indicator bars turn green.

Navigating with the Map

- 1 Begin navigating to a destination ([Navigating to a Destination, page 4](#)).
- 2 Select **Map**.

A blue triangle represents your location on the map. As you travel, the blue triangle moves and leaves a track log (trail).

- 3 Complete one or more actions:
 - Select **⦿**, and drag the map to view different areas.
 - Select **+** and **-** to zoom in and out of the map.
 - Select a location on the map (represented by a pin), and select the information bar at the top of the screen to view information about the selected location.

Navigating a Driving Route

Before you can navigate street routes, you must purchase and load City Navigator maps.

- 1 Select **Profile Change > Automotive**.
- 2 Select a destination.
- 3 Navigate using the map.
Turns appear in the information bar along the top of the map. Audible tones signal turns in the route.

Navigating with the Compass

When navigating to a destination, **▲** points to your destination, regardless of the direction you are moving.

- 1 Begin navigating to a destination ([Navigating to a Destination, page 4](#)).
- 2 Select **Compass**.
- 3 Turn until **▲** points toward the top of the compass, and continue moving in that direction to the destination.

Calibrating the Compass

NOTICE

Calibrate the electronic compass outdoors. To improve heading accuracy, do not stand near objects that influence magnetic fields, such as vehicles, buildings, and overhead power lines.


Your device was already calibrated at the factory, and the device uses automatic calibration by default. If you experience irregular compass behavior, for example, after moving long distances or after extreme temperature changes, you can manually calibrate the compass.

- 1 Select **Compass**.
- 2 Swipe up from the bottom of the screen, and select **≡ > Calibrate Compass > Start**.
- 3 Follow the on-screen instructions.

Course Pointer

The course pointer is most useful if you are navigating on water or where there are no major obstacles in your path. It also can also help you avoid hazards to either side of the course, such as shoals or submerged rocks.

To enable the course pointer, from the compass, select **Setup > Heading > Go To Line (Pointer) > Course (CDI)**.



The course pointer ① indicates your relationship to the course line leading to the destination. The course deviation indicator (CDI) ② provides the indication of drift (right or left) from the course. The scale ③ refers to the distance between dots ④ on the course deviation indicator, which tell you how far off course you are.

Marking and Starting Navigation to a Man Overboard Location

You can save a man overboard (MOB) location, and automatically start navigation back to it.

- 1 Select **Man Overboard > Start**.

The map opens showing the route to the MOB location. The default appearance of the route is a magenta line.

- 2 Navigate using the map (*Navigating with the Map, page 4*) or compass (*Navigating with the Compass, page 4*).

Navigating with Sight 'N Go

You can point the device at an object in the distance, lock in the direction, and navigate to the object.

- 1 Select **Sight 'N Go**.
- 2 Point the device at an object.
- 3 Select **Lock Direction > Set Course**.
- 4 Navigate using the compass.

Elevation Plot

By default, the elevation plot displays the elevation over the distance traveled. To customize the elevation settings, see *Altimeter Settings, page 10*. You can touch any point on the plot to view details about that point.

Navigating to a Point on the Plot

- 1 Select **Elevation Plot**.
- 2 Select an individual point on the plot.
- 3 Select ↩.
- 4 Select the information bar at the top of the screen.
- 5 Navigate using the map (*Navigating with the Map, page 4*) or compass (*Navigating with the Compass, page 4*).

Changing the Plot Type

You can change the elevation plot to display pressure and elevation over time or distance.

- 1 Select **Elevation Plot**.
- 2 Swipe up from the bottom of the screen, and select ≡ > **Change Plot Type**.
- 3 Select an option.

Resetting the Elevation Plot

- 1 Select **Elevation Plot**.
- 2 Swipe up from the bottom of the screen, and select ≡ > **Reset > Clear Current Track > Clear**.

Calibrating the Barometric Altimeter

Your device was already calibrated at the factory, and the device uses automatic calibration by default. You can manually calibrate the barometric altimeter if you know the correct elevation or the correct barometric pressure.

- 1 Go to a location where the elevation or barometric pressure is known.
- 2 Select **Elevation Plot**.
- 3 Swipe up from the bottom of the screen, and select ≡ > **Calibrate Altimeter**.
- 4 Follow the on-screen instructions.

Geocaches

A geocache is like a hidden treasure. Geocaching is when you hunt for hidden treasures using GPS coordinates posted online by those hiding the geocache.

Downloading Geocaches

- 1 Connect the device to your computer using a USB cable.
- 2 Go to www.garmin.com/geocaching.
- 3 If necessary, create an account.
- 4 Sign in.
- 5 Follow the on-screen instructions to find and download geocaches to your device.

Filtering the Geocache List

You can filter your geocache list based on certain factors, such as the level of difficulty.

- 1 Select **Geocaching > Quick Filter**.
- 2 Select one or more items to filter.
- 3 Customize the settings, and select ↩.
- 4 Select an option:
 - To apply the filter to the geocache list, select **Search**.
 - To save the filter, select ↩.

Creating and Saving a Geocache Filter

You can create and save custom filters for geocaches based on specific factors. After you set up the filter, you can apply it in the geocaches list.

- 1 Select **Setup > Geocaching > Filter Setup > Create Filter**.
- 2 Select filter options.
- 3 Select ↩.

The filter is named automatically.

Editing a Custom Geocache Filter

- 1 Select **Setup > Geocaching > Filter Setup**.
- 2 Select a filter.
- 3 Select an item to edit.

Navigating to a Geocache

- 1 Select **Geocaching > Find a Geocache**.
- 2 Select a geocache.
- 3 Select **Go**.
- 4 Navigate using the map (*Navigating with the Map, page 4*) or compass (*Navigating with the Compass, page 4*).

chirp™

A chirp is a small Garmin accessory that is programmed and left in a geocache. You can use your device to find a chirp in a geocache. For more information about the chirp, see the *chirp Owner's Manual* at www.garmin.com.

Enabling chirp Searching

- 1 Select **Setup** > **Geocaching**.
- 2 Select **chirp Searching** > **On**.

Finding a Geocache with a chirp

- 1 Select **Geocaching** > **Find a Geocache**.
- 2 Select a geocache.
- 3 Select **Go**.
- 4 Navigate using the map (*Navigating with the Map*, page 4) or compass (*Navigating with the Compass*, page 4).

When you are within approximately 32.9 ft (10 m) of the geocache that contains a chirp, details about the chirp appear.

- 5 If necessary, select **Geocaching** > **Show chirp Details**.
- 6 If available, select **Go** to navigate to the next stage of the geocache.

Logging the Attempt

Before you can log an attempt to find a geocache, you must start navigating to the geocache (*Navigating to a Geocache*, page 5).

After attempting to find a geocache, you can log your results.

- 1 Select **Geocaching** > **Log Attempt**.
- 2 Select **Found**, **Did Not Find**, or **Needs Repair**.
- 3 Select an option:
 - To begin navigation to the next geocache nearest you, select **Find Next Closest**.
 - To stop logging, select **Done**.
 - To enter a comment about looking for the cache or about the cache itself, select **Edit Comment**, enter a comment, and select ✓.

Applications

Sending and Receiving Data Wirelessly

Before you can share data wirelessly, you must be within 10 feet (3 m) of a compatible device.

Your device can send and receive data when paired with another compatible device or smartphone using ANT+® wireless technology. You can share waypoints, geocaches, routes, and tracks.

NOTE: This feature is not available for all device models.

- 1 Select **Share Wirelessly**.
- 2 Select an option:
 - Select **Send**, and select a type of data.
 - Select **Receive** to receive data from another device. The other compatible device must be attempting to send data.
- 3 Follow the on-screen instructions.

Setting a Proximity Alarm

Proximity alarms alert you when you are within a specified range of a particular location.

- 1 Select **Proximity Alarms** > **Create Alarm**.
- 2 Select a category.
- 3 Select a location.
- 4 Select **Use**.

- 5 Enter a radius, and select ✓.

When you enter an area with a proximity alarm, the device sounds a tone.

Calculating the Size of an Area

- 1 Select **Area Calculation** > **Start**.
- 2 Walk around the perimeter of the area you want to calculate.
- 3 Select **Calculate** when finished.

Viewing the Calendar and Almanacs

You can view device activity, such as when a waypoint was saved, and almanac information for the sun and moon, and hunting and fishing.

- 1 Select an option:
 - To view device activity for specific days, select **Calendar**.
 - To view the sunrise, sunset, moonrise, and moonset information, select **Sun and Moon**.
 - To view the predicted best times for hunting and fishing, select **Hunt and Fish**.
- 2 If necessary, select ◀ or ▶ to view a different month.
- 3 Select a day.

Setting an Alarm

If you are not currently using the device, you can set the device to turn on at a specific time.

- 1 Select **Alarm Clock**.
- 2 Select + and - to set the time.
- 3 Select **Turn Alarm On**.
- 4 Select an option.

The alarm sounds at the selected time. If the device is off at the alarm time, the device turns on and sounds the alarm.

Starting the Countdown Timer

- 1 Select **Alarm Clock** > ≡ > **Timer**.
- 2 Select + and - to set the time.
- 3 Select **Start Timer**.

Opening the Stopwatch

Select **Stopwatch**.

Satellite Page

The satellite page shows your current location, GPS accuracy, satellite locations, and signal strength.

Changing the Satellite View

- 1 Select **Satellite**.
- 2 Swipe up from the bottom of the screen, and select ≡.
- 3 Select **Track Up** to orient the satellite view with your current track toward the top of the screen.
- 4 Select **Multicolor** to assign a specific color to the satellite and to the signal strength bar of that satellite.

Turning Off GPS

- 1 Select **Satellite**.
- 2 Swipe up from the bottom of the screen, and select ≡ > **Use With GPS Off**.

Simulating a Location


- 1 Select **Satellite**.
- 2 Swipe up from the bottom of the screen, and select ≡ > **Use With GPS Off**.
- 3 Swipe up from the bottom of the screen, and select ≡ > **Set Loc. On Map**.

- 4 Select a location.
- 5 Select **Use**.

Controlling a VIRB® Action Camera

Before you can use the VIRB remote function, you must enable the remote setting on your VIRB camera. See the *VIRB Series Owner's Manual* for more information.

NOTE: This feature is not available for all device models.

- 1 Turn on your VIRB camera.
- 2 From your device, select **VIRB Remote**.
- 3 Wait while the device connects with your VIRB camera.
- 4 Select an option:
 - To record video, drag the slider bar up.
 - To take a photo, select .

Phone Notifications

NOTE: This feature is not available for all device models.

Phone notifications require a compatible smartphone to be paired with the device. When your phone receives messages, it sends notifications to your device.


Pairing a Smartphone with Your Device

Before you can pair your smartphone with your device, you must download and install the Garmin Connect™ Mobile app. Go to garmin.com/intosports/apps for more information.

- 1 Bring your compatible smartphone within 10 m (33 ft.) of your device.
- 2 On your compatible smartphone, enable Bluetooth® wireless technology.
- 3 Open the Garmin Connect Mobile app.
- 4 Select **Setup > Bluetooth > Pair Mobile Device**.
- 5 Follow the on-screen instructions.

Hiding Notifications

Notifications are enabled by default when you pair your device with a compatible smartphone. You can hide notifications so they do not appear on your device screen.

Select  > **Bluetooth > Notifications > Hide**.



Fitness

Running or Cycling with Your Device

Before you go for a run or ride using the device, you must select an appropriate profile ([Selecting a Profile, page 9](#)).

You can customize your dashboards and data fields for your fitness activities ([Custom Data Fields and Dashboards, page 8](#)).

- 1 If your device is currently recording a track, select **Current Track > II**.

You can save or delete the current track.
- 2 Select  > **Setup > Activities > Advanced Setup > Output Format**.
- 3 Select an option:
 - Select **Activities (FIT)** to record your activity with fitness information (for example, laps) that is tailored for Garmin Connect.
 - Select **Tracks (GPX/FIT)** to record your activity as both a traditional track that can be viewed on the map and used for navigation, and as an activity with fitness information.
- 4 Select  > **Stopwatch > Start**.
- 5 Go for a run or ride.
- 6 When finished, select **Stop**.

- 7 Select **Reset > Save**.

History

History includes date, time, distance, calories, average speed or pace, ascent, descent, and optional ANT+ sensor information.

NOTE: History is not recorded while the timer is stopped or paused.

When the device memory is full, a message appears. The device does not automatically delete or overwrite your history. You can upload your history to Garmin Connect ([Using Garmin Connect, page 7](#)) or BaseCamp ([Garmin® Adventures, page 3](#)) periodically to keep track of all your activity data.

Viewing an Activity

- 1 Select **Activity History**.
- 2 Select an activity.
- 3 Select **Review**.

Deleting an Activity

- 1 Select **Activity History**.
- 2 Select an activity.
- 3 Select **Delete > Yes**.

Using Garmin Connect

- 1 Connect the device to your computer using the USB cable.
- 2 Go to www.garminconnect.com/start.
- 3 Follow the on-screen instructions.

Optional Fitness Accessories

You can use optional fitness accessories including a heart rate monitor or a cadence sensor with your device. These accessories use ANT+ wireless technology to send data to the device.

Before you can use the fitness accessory with your device, you must install the accessory according to the instructions included with the accessory.

Pairing Your ANT+ Sensors

Before you can pair, you must put on the heart rate monitor or install the sensor.

The device is compatible with the heart rate monitor, GSC™ 10 speed and cadence sensor, and *tempe*™ wireless temperature sensor. You can customize a data field to display sensor data.

- 1 Bring the device within range (3 m) of the sensor.

NOTE: Stay 10 m away from other ANT+ sensors while pairing.
- 2 Select **Setup > ANT Sensor**.
- 3 Select your sensor.
- 4 Select **Search for New**.

When the sensor is paired with your device, the sensor status changes from Searching to Connected.

Tips for Pairing ANT+ Accessories with Your Garmin Device

- Verify that the ANT+ accessory is compatible with your Garmin device.
- Before you pair the ANT+ accessory with your Garmin device, move 10 m (32.9 ft.) away from other ANT+ accessories.
- Bring the Garmin device within range 3 m (10 ft.) of the ANT+ accessory.
- After you pair the first time, your Garmin device automatically recognizes the ANT+ accessory each time it is activated. This process occurs automatically when you turn on the Garmin device and only takes a few seconds when the accessories are activated and functioning correctly.
- When paired, your Garmin device receives data from only your accessory, and you can go near other accessories.

About Heart Rate Zones

Many athletes use heart rate zones to measure and increase their cardiovascular strength and improve their level of fitness. A heart rate zone is a set range of heartbeats per minute. The five commonly accepted heart rate zones are numbered from 1 to 5 according to increasing intensity. Generally, heart rate zones are calculated based on percentages of your maximum heart rate.

Fitness Goals

Knowing your heart rate zones can help you measure and improve your fitness by understanding and applying these principles.

- Your heart rate is a good measure of exercise intensity.
- Training in certain heart rate zones can help you improve cardiovascular capacity and strength.
- Knowing your heart rate zones can prevent you from overtraining and can decrease your risk of injury.

If you know your maximum heart rate, you can use the table ([Heart Rate Zone Calculations, page 14](#)) to determine the best heart rate zone for your fitness objectives.

If you do not know your maximum heart rate, use one of the calculators available on the Internet. Some gyms and health centers can provide a test that measures maximum heart rate. The default maximum heart rate is 220 minus your age.

Setting Your Heart Rate Zones

Before the device can determine your heart rate zones, you must set up your fitness user profile ([Setting Your Fitness User Profile, page 10](#)).

You can manually adjust the heart rate zones according to your fitness goals ([Fitness Goals, page 8](#)).


- 1 Select **Setup > Fitness > HR Zones**.
- 2 Enter the maximum and minimum heart rate for zone 5.
The maximum heart rate for each zone is based on the minimum heart rate of the previous zone. For example, if you enter 167 as a minimum heart rate for zone 5, the device uses 166 as the maximum rate for zone 4.
- 3 Enter your minimum heart rate for zones 4-1.

Customizing the Device

Adjusting the Backlight Brightness

Extensive use of screen backlighting can significantly reduce battery life. You can adjust the backlight brightness to maximize the battery life.

NOTE: The backlight brightness may be limited when the battery is low.

- 1 Select .
- 2 Use the slider to adjust the backlight level.

The device may feel warm when the backlight setting is high.

Locking the Touchscreen

You can lock the screen to prevent inadvertent screen touches.

Select  > .

Unlocking the Touchscreen

Select  > .

Setting the Touchscreen Sensitivity

You can adjust the touchscreen sensitivity to suit your activity.

- 1 Select **Setup > Accessibility > Touch Sensitivity**.
- 2 Select an option.

TIP: You can test the touchscreen settings with and without gloves based on your activity.

Display Settings

Select **Setup > Display**.

Backlight Timeout: Sets the length of time before the backlight turns off.

Screen Capture: Allows you to save the image on the device screen.

Battery Save: Saves the battery power and prolongs the battery life by turning off the screen when the backlight times out ([Turning On Battery Save Mode, page 11](#)).

Configuring the Maps

You can enable or disable the maps currently loaded on the device.

Select **Setup > Map > Configure Maps**.

General Map Settings

Select **Setup > Map > General**.

Detail: Sets the amount of detail shown on the map. Showing more detail may cause the map to redraw more slowly.

Orientation: Adjusts how the map is shown on the page. The North Up option shows north at the top of the page. The Track Up option shows your current direction of travel toward the top of the page. The Automotive Mode option shows an automotive perspective with the direction of travel at the top.

Dashboard: Sets a dashboard to display on the map. Each dashboard shows different information about your route or your location.

Shaded Relief: Shows detail relief on the map (if available) or turns off shading.

Auto Zoom: Sets the display to automatic zoom.

Advanced Map Settings

Select **Setup > Map > Advanced Setup**.

Map Speed: Adjusts the speed at which the map is drawn. A faster map drawing speed decreases the battery life.

Guidance Text: Sets when the guidance text is shown on the map.

Select Vehicle: Sets the position icon, which represents your position the map. The default icon is a small blue triangle.

Zoom Levels: Adjusts the zoom level at which map items appear. The map items do not appear when the map zoom level is higher than the selected level.


Text Size: Sets the text size for map items.

Custom Data Fields and Dashboards

Data fields display information about your location or other specified data. Dashboards are a custom grouping of data that can be helpful to a specific or general task, such as geocaching.

You can customize the data fields and dashboards of the map, compass, trip computer, elevation plot, and the status page.

Enabling the Map Data Fields

- 1 From the map, swipe up from the bottom of the screen and select  > **Setup Map > General > Dashboard**.
- 2 Select a data field.

Customizing the Data Fields


Before you can change the map data fields, you must enable them ([Enabling the Map Data Fields, page 8](#)).

You can customize the data fields and dashboards of the map, compass, trip computer, elevation plot, and status pages.

- 1 From a page that displays data fields, select a data field.
- 2 Select a data field category and a data field.

For example, select **Trip Data > Speed - Moving Avg.**

Customizing Dashboards

- 1 Select a page.
- 2 From the map, swipe up from the bottom of the screen and select  > **Setup Map** > **General** > **Dashboard**.
- 3 Select a dashboard.

Profiles

Profiles are a collection of settings that optimize your device based on how you are using it. For example, the settings and views are different when you use the device for hunting than when geocaching.

Profiles are associated with the activity screens, including the home screen.

When you are using a profile and you change settings, such as data fields or units of measurement, the changes are saved automatically as part of the profile.

Selecting a Profile

When you change activities, your settings are different for each profile.

- 1 From the home screen, swipe the screen horizontally.
- 2 Select a profile.

Creating a Custom Profile

You can customize your settings and data fields for a particular activity or trip.

- 1 Select **Setup** > **Profiles** > **Create Profile** > **OK**.
- 2 Customize your settings and data fields.

Editing a Profile Name

- 1 Select **Setup** > **Profiles**.
- 2 Select a profile.
- 3 Select **Edit Name**.
- 4 Enter the new name.

Deleting a Profile

NOTE: Before you can delete the active profile, you must activate a different profile. You cannot delete a profile while it is active.

- 1 Select **Setup** > **Profiles**.
- 2 Select a profile.
- 3 Select **Delete**.

System Settings

Select **Setup** > **System**.

Satellite System: Sets the satellite system to GPS, Satellite System ([GPS and GLONASS, page 9](#)), or Demo Mode (GPS off).

WAAS/EGNOS: Sets the system to Wide Area Augmentation System/European Geostationary Navigation Overlay Service (WAAS/EGNOS). For more information about WAAS, go to www.garmin.com/aboutGPS/waas.html.

Text Language: Sets the text language on the device.

NOTE: Changing the text language does not change the language of user-entered data or map data.

USB Mode: Sets the device to use mass storage mode or Garmin mode when connected to a computer.

Battery Type: Sets the battery type for the device.

GPS and GLONASS

The default satellite system setting is Satellite System, which offers increased performance in challenging environments and faster position acquisition. Using GPS and GLONASS can reduce battery life more quickly than using GPS only.

Display Settings

Select **Setup** > **Display**.

Backlight Timeout: Sets the length of time before the backlight turns off.

Screen Capture: Allows you to save the image on the device screen.

Battery Save: Saves the battery power and prolongs the battery life by turning off the screen when the backlight times out ([Turning On Battery Save Mode, page 11](#)).

Appearance Settings

Select **Setup** > **Appearance**.

Mode: Sets a light background, a dark background, or automatically switches between the two based on the sunrise and sunset time for your current location.

Day Color: Sets the color for the selections made when in day mode.

Night Color: Sets the color for the selections made when in night mode.

Setting the Device Tones

You can customize tones for messages, keys, turn warnings, and alarms.

- 1 Select **Setup** > **Tones** > **Tones** > **On**.
- 2 Select a tone for each audible type.

Tracks Settings

Select **Setup** > **Tracks**.

Record Method: Sets a track recording method. The Auto option records the tracks at a variable rate to create an optimum representation of your tracks.

Interval: Sets a track log recording rate. Recording points more frequently creates a more-detailed track, but fills the track log faster.

Auto Pause: Pauses tracking automatically when you stop moving.

Auto Start: Starts recording a track automatically when the device has acquired satellites.

Advanced Setup: Allows you to set up automatic archiving, set up when to record trip data, choose the format for recording a track log, and reset trip data.

Routing Settings

The device calculates routes optimized for the type of activity you are doing. The available routing settings vary based on the activity selected.

Select **Setup** > **Routing**.

Activity: Sets an activity for routing. The device calculates routes optimized for the type of activity you are doing.

Route Transitions: Sets how the device routes from one point on the route to the next. This setting is available only for some activities. Distance routes you to the next point on the route when you are within a specified distance of your current point.

Lock On Road: Locks the blue triangle, which represents your position on the map, onto the nearest road.

Heading Settings

You can customize the compass settings.

Select **Setup** > **Heading**.

Display: Sets the type of directional heading shown on the compass.

North Reference: Sets the north reference used on the compass.

Go To Line (Pointer): Allows you to use the bearing pointer that points in the direction of your destination, or use the course pointer that shows your relationship to the course line leading to the destination.

Compass: Automatically switches from an electronic compass to a GPS compass when you are traveling at a higher rate of speed for a period of time.

Calibrate Compass: Allows you to calibrate the compass if you experience irregular compass behavior, for example, after moving long distances or after extreme temperature changes. See [Calibrating the Compass, page 4](#).

Altimeter Settings

Select **Setup > Altimeter**.

Auto Calibration: Automatically calibrates the altimeter each time the device is turned on. The device continues to automatically calibrate the altimeter as long as the device has GPS signals acquired.

Barometer Mode: Variable Elevation allows the barometer to measure changes in elevation while you are moving. Fixed Elevation assumes the device is stationary at a fixed elevation, so the barometric pressure should only change due to weather.

Pressure Trending: Sets how the device records pressure data. Save Always can be useful when you are watching for pressure fronts.

Plot Type: Records elevation changes over a period of time or distance, records barometric pressure over a period of time, or records ambient pressure changes over a period of time.

Calibrate Altimeter: Allows you to calibrate the barometric altimeter if you know the correct elevation or the correct barometric pressure. See [Calibrating the Barometric Altimeter, page 5](#).

Position Format Settings

NOTE: You should not change the position format or the map datum coordinate system unless you are using a map or chart that specifies a different position format.

Select **Setup > Position Format**.

Position Format: Sets the position format in which a location reading appears.

Map Datum: Sets the coordinate system on which the map is structured.

Map Spheroid: Shows the coordinate system the device is using. The default coordinate system is WGS 84.

Changing the Units of Measure

You can customize units of measure for distance and speed, elevation, depth, temperature, pressure, and vertical speed.

- 1 Select **Setup > Units**.
- 2 Select a measurement type.
- 3 Select a unit of measure.

Time Settings

Select **Setup > Time**.

Time Format: Sets the device to show time in a 12-hour or 24-hour format.

Time Zone: Sets the time zone for the device. Automatic sets the time zone automatically based on your GPS position.

Geocaching Settings

Select **Setup > Geocaching**.

Appearance: Allows you to set the display style for geocache data, and display the geocache list by names or codes.

chirp Searching: Allows the device to search for a geocache containing a chirp accessory ([Enabling chirp Searching, page 6](#)).

Program chirp: Programs the chirp accessory. See the *chirp Owner's Manual* at www.garmin.com.

Filter Setup: Allows you to create and save custom filters for geocaches ([Creating and Saving a Geocache Filter, page 5](#)).

Found Geocaches: Allows you to edit the number of geocaches found. This number automatically increases when you log a find ([Logging the Attempt, page 6](#)).

ANT+ Sensor Settings

For more information about optional fitness accessories, see [Optional Fitness Accessories, page 7](#).

Fitness Settings

Select **Setup > Fitness**.

Auto Lap: Sets the device to automatically mark the lap at a specific distance.

User: Sets the user profile information ([Setting Your Fitness User Profile, page 10](#)).

HR Zones: Sets the five heart rate zones for fitness activities.

Activity Type: Sets the fitness activity to running, cycling, or other. This allows your running activity to appear as a running activity when you transfer it to Garmin Connect.

Setting Your Fitness User Profile

The device uses information that you enter about yourself to calculate accurate data. You can modify the following user profile information: gender, age, weight, height, and lifetime athlete ([About Lifetime Athletes, page 10](#)).

- 1 Select **Setup > Fitness > User**.
- 2 Modify the settings.

About Lifetime Athletes

A lifetime athlete is an individual who has trained intensely for many years (with the exception of minor injuries) and has a resting heart rate of 60 beats per minute (bpm) or less.

Marking Laps by Distance

You can use Auto Lap® to automatically mark the lap at a specific distance. This feature is helpful for comparing your performance over different parts of an activity.

- 1 Select **Setup > Fitness > Auto Lap**.
- 2 Enter a value, and select ✓.

Marine Settings

Select **Setup > Marine**.

Marine Chart Mode: Sets the type of chart the device uses when displaying marine data. Nautical displays various map features in different colors so the marine POIs are more readable and so the map reflects the drawing scheme of paper charts. Fishing (requires marine maps) displays a detailed view of bottom contours and depth soundings and simplifies map presentation for optimal use while fishing.

Appearance: Sets the appearance of marine navigation aids on the map.

Marine Alarm Setup: Sets alarms for when you exceed a specified drift distance while anchored, when you are off course by a specified distance, and when you enter water of a specific depth.

Setting Up Marine Alarms

- 1 Select **Setup > Marine > Marine Alarm Setup**.

- 2 Select an alarm type.
- 3 Select **On**.
- 4 Enter a distance, and select ✓.

Resetting Data

You can reset trip data, delete all waypoints, clear the current track, or restore default values.

- 1 Select **Setup > Reset**.
- 2 Select an item to reset.

Restoring Default Values for Specific Settings

- 1 Select **Setup**.
- 2 Select an item to reset.
- 3 Select ☰ > **Restore Defaults**.

Restoring Default Values for Specific Page Settings

You can restore the default values for settings for the map, compass, trip computer, and elevation plot.

- 1 Open the page for which you will restore the settings.
- 2 Select ☰ > **Restore Defaults**.

Restoring All Default Settings

You can reset all settings back to the factory default settings.

Select **Setup > Reset > Reset All Settings > Yes**.

Device Information

Specifications

Battery type	2 AA batteries, (alkaline, NiMH, lithium, or precharged NiMH)
Battery life	Up to 16 hr.
Operating temperature range	From -20°C to 70°C (from -4°F to 158°F)
Radio frequency/protocol	2.4 GHz ANT+ wireless technology Bluetooth Smart device
Water rating	IEC 60529 IPX7*
Compass-safe distance	30 cm (11.8 in.)

*The device withstands incidental exposure to water of up to 1 m for up to 30 min. For more information, go to www.garmin.com/waterrating.

Support and Updates

Garmin Express™ (garmin.com/express) provides easy access to these services for Garmin devices.

- Product registration
- Product manuals
- Data uploads to Garmin Connect

Setting Up Garmin Express

- 1 Connect the device to your computer using a USB cable.
- 2 Go to www.garmin.com/express.
- 3 Follow the on-screen instructions.

Getting More Information

You can find more information about this product on the Garmin website.

- Go to www.garmin.com/outdoor.
- Go to <http://buy.garmin.com>, or contact your Garmin dealer for information about optional accessories and replacement parts.

Registering Your Device

Help us better support you by completing our online registration today.

- Go to garmin.com/express.
- Keep the original sales receipt, or a photocopy, in a safe place.

Battery Information

⚠ WARNING

The temperature rating for the device may exceed the usable range of some batteries. Alkaline batteries can rupture at high temperatures.

Do not use a sharp object to remove batteries.

⚠ CAUTION

Contact your local waste disposal department to properly recycle the batteries.

NOTICE

Alkaline batteries lose a significant amount of their capacity as the temperature decreases. Use lithium batteries when operating the device in below freezing conditions.

Maximizing the Battery Life

You can do several things to extend the life of the batteries.

- Reduce the backlight brightness ([Adjusting the Backlight Brightness, page 8](#)).
- Reduce the backlight timeout ([Display Settings, page 8](#)).
- Use battery save mode ([Turning On Battery Save Mode, page 11](#)).
- Decrease the map drawing speed ([Configuring the Maps, page 8](#)).

Turning On Battery Save Mode

You can use battery save mode to prolong the battery life.

Select **Setup > Display > Battery Save > On**.

In battery save mode, the screen shuts off when the backlight times out. You can select ⏻ to turn on the screen, and you can double tap ⏻ to view the status page.

Long-Term Storage

When you do not plan to use the device for several months, remove the batteries. Stored data is not lost when batteries are removed.

Device Care

NOTICE

Do not store the device where prolonged exposure to extreme temperatures can occur, because it can cause permanent damage.

Never use a hard or sharp object to operate the touchscreen, or damage may result.

Avoid chemical cleaners, solvents, and insect repellents that can damage plastic components and finishes.

Secure the weather cap tightly to prevent damage to the USB port.

Cleaning the Device

NOTICE

Even small amounts of sweat or moisture can cause corrosion of the electrical contacts when connected to a charger. Corrosion can prevent charging and data transfer.

- 1 Wipe the device using a cloth dampened with a mild detergent solution.

- 2 Wipe it dry.

After cleaning, allow the device to dry completely.

Cleaning the Touchscreen

- 1 Use a soft, clean, lint-free cloth.
- 2 If necessary, lightly dampen the cloth with water.
- 3 If using a dampened cloth, turn off the device and disconnect the device from power.
- 4 Gently wipe the screen with the cloth.

Water Immersion

NOTICE

The device is water resistant to IEC Standard 60529 IPX7. It can withstand immersion in 1 meter of water for 30 minutes. Prolonged submersion can cause damage to the device. After submersion, be certain to wipe dry and air dry the device before using or charging.

Data Management

NOTE: The device is not compatible with Windows 95, 98, Me, Windows NT®, and Mac OS 10.3 and earlier.

File Types


The handheld device supports these file types:

- Files from BaseCamp or HomePort™. Go to www.garmin.com/trip_planning.
- GPX track files.
- GPX geocache files ([Downloading Geocaches, page 5](#)).
- JPEG photo files.
- GPI custom POI files from the Garmin POI Loader. Go to www.garmin.com/products/poiloader.
- FIT files for exporting to Garmin Connect.

Installing a Memory Card

You can install a microSD memory card for additional storage or pre-loaded maps.

- 1 Turn the D-ring counter-clockwise, and pull up to remove the cover.
- 2 Remove the batteries.
- 3 In the battery compartment, slide the card holder ① to the left and lift up.



- 4 Place the memory card ② with the gold contacts facing down.
- 5 Close the card holder.
- 6 Slide the card holder to the right to lock it.
- 7 Replace the batteries.
- 8 Replace the battery cover, and turn the D-ring clockwise.

Connecting the Device to Your Computer

NOTICE

To prevent corrosion, thoroughly dry the USB port, the weather cap, and the surrounding area before charging or connecting to a computer.

- 1 Pull up the weather cap from the USB port.

- 2 Plug the small end of the USB cable into the USB port on the device.
- 3 Plug the large end of the USB cable into a computer USB port.

Your device and memory card (optional) appear as removable drives in My Computer on Windows computers and as mounted volumes on Mac computers.

Transferring Files to Your Device

- 1 Connect the device to your computer.

On Windows computers, the device appears as a removable drive or a portable device, and the memory card may appear as a second removable drive. On Mac computers, the device and memory card appear as mounted volumes.

NOTE: Some computers with multiple network drives may not display device drives properly. See your operating system documentation to learn how to map the drive.

- 2 On your computer, open the file browser.
- 3 Select a file.
- 4 Select **Edit > Copy**.
- 5 Open the portable device, drive, or volume for the device or memory card.
- 6 Browse to a folder.
- 7 Select **Edit > Paste**.

The file appears in the list of files in the device memory or on the memory card.

Deleting Files

NOTICE

If you do not know the purpose of a file, do not delete it. Your device memory contains important system files that should not be deleted.

- 1 Open the **Garmin** drive or volume.
- 2 If necessary, open a folder or volume.
- 3 Select a file.
- 4 Press the **Delete** key on your keyboard.

Disconnecting the USB Cable

If your device is connected to your computer as a removable drive or volume, you must safely disconnect your device from your computer to avoid data loss. If your device is connected to your Windows computer as a portable device, it is not necessary to safely disconnect.

- 1 Complete an action:
 - For Windows computers, select the **Safely Remove Hardware** icon in the system tray, and select your device.
 - For Mac computers, drag the volume icon to the trash.
- 2 Disconnect the cable from your computer.

Troubleshooting

Resetting the Device

If the device stops responding, you may need to reset it. This does not erase any of your data or settings.

- 1 Remove the batteries.
- 2 Reinstall the batteries.

Viewing Device Information

You can view the unit ID, software version, and license agreement.

Select **Setup > About**.

Appendix

tempe

The tempe is an ANT+ wireless temperature sensor. You can attach the sensor to a secure strap or loop where it is exposed to ambient air, and therefore, provides a consistent source of accurate temperature data. You must pair the tempe with your device to display temperature data from the tempe.

Data Fields

Some data fields require you to be navigating or require ANT+ accessories to display data.

24hr Max Temperature: The maximum temperature recorded in the last 24 hours.

24hr Min Temperature: The minimum temperature recorded in the last 24 hours.

Accuracy Of GPS: The margin of error for your exact location. For example, your GPS location is accurate to within +/- 12 ft. (3.65 m).

Alarm Timer: The current time of the countdown timer.

Ambient Pressure: The uncalibrated environmental pressure.

Ascent - Average: The average vertical distance of ascent since the last reset.

Ascent - Maximum: The maximum rate of ascent in feet per minute or meters per minute since the last reset.

Ascent - Total: The total elevation distance ascended since the last reset.

Automotive Turn: The direction of the next turn in the route. You must be navigating for this data to appear.

Average Cadence: The average cadence for the current activity.

Average Heart Rate: The average heart rate for the current activity.

Average Lap: The average lap time for the current activity.

Avg. Heart Rate Percent: The average percentage of maximum heart rate for the current activity.

Barometer: The calibrated current pressure.

Battery Level: The remaining battery power.

Bearing: The direction from your current location to a destination. You must be navigating for this data to appear.

Cadence: The number of revolutions of the crank arm or number of strides per minute. Your device must be connected to a cadence accessory for this data to appear.

Calories: The amount of total calories burned.

Compass Heading: The direction you are moving based on the compass.

Course: The direction from your starting location to a destination. Course can be viewed as a planned or set route. You must be navigating for this data to appear.

Current Lap: The stopwatch time for the current lap.

Date: The current day, month, and year.

Depth: The depth of the water. Your device must be connected to a NMEA® 0183 or NMEA 2000® device capable of acquiring the water depth.

Descent - Average: The average vertical distance of descent since the last reset.

Descent - Maximum: The maximum rate of descent in feet per minute or meters per minute since the last reset.

Descent - Total: The total elevation distance descended since the last reset.

Distance To Destination: The remaining distance to the final destination. You must be navigating for this data to appear.

Distance To Next: The remaining distance to the next waypoint on the route. You must be navigating for this data to appear.

Elapsed (Total) Time: The total time recorded. For example, if you start the timer and run for 10 minutes, then stop the timer for 5 minutes, then start the timer and run for 20 minutes, your elapsed time is 35 minutes.

Elevation: The altitude of your current location above or below sea level.

Elevation Above Ground: The altitude of your current location above ground level (if maps contain sufficient elevation information).

Elevation - Maximum: The highest elevation reached since the last reset.

Elevation - Minimum: The lowest elevation reached since the last reset.

ETA At Destination: The estimated time of day when you will reach the final destination (adjusted to the local time of the destination). You must be navigating for this data to appear.

ETA At Next: The estimated time of day when you will reach the next waypoint on the route (adjusted to the local time of the waypoint). You must be navigating for this data to appear.

Glide Ratio: The ratio of horizontal distance traveled to the change in vertical distance.

Glide Ratio To Dest: The glide ratio required to descend from your current position to the destination elevation. You must be navigating for this data to appear.

GPS Elevation: The altitude of your current location using GPS.

GPS Heading: The direction you are moving based on GPS.

GPS Signal Strength: The strength of the GPS satellite signal.

Grade: The calculation of rise (elevation) over run (distance). For example, if for every 10 ft. (3 m) you climb you travel 200 ft. (60 m), the grade is 5%.

Heading: The direction you are moving.

Heart Rate: Your heart rate in beats per minute (bpm). Your device must be connected to a compatible heart rate monitor.

Heart Rate Percent Max: The percentage of maximum heart rate.

Heart Rate Zone: The current range of your heart rate (1 to 5). The default zones are based on your user profile and maximum heart rate (220 minus your age).

Lap Ascent: The vertical distance of ascent for the current lap.

Lap Cadence: The average cadence for the current lap.

Lap Descent: The vertical distance of descent for the current lap.

Lap Distance: The distance traveled for the current lap.

Lap Heart Rate: The average heart rate for the current lap.

Lap Heart Rate Percent: The average percentage of maximum heart rate for the current lap.

Laps: The number of laps completed for the current activity.

Lap Speed: The average speed for the current lap.

Last Lap Ascent: The vertical distance of ascent for the last completed lap.

Last Lap Cadence: The average cadence for the last completed lap.

Last Lap Descent: The vertical distance of descent for the last completed lap.

Last Lap Distance: The distance traveled for the last completed lap.

Last Lap Heart Rate: The average heart rate for the last completed lap.

Last Lap Speed: The average speed for the last completed lap.

Last Lap Time: The stopwatch time for the last completed lap.

Location (lat/lon): The current position in latitude and longitude regardless of the selected position format setting.

Location (selected): The current position using the selected position format setting.

Location of Destination: The position of your final destination. You must be navigating for this data to appear.

None: This is a blank data field.

Odometer: A running tally of distance traveled for all trips. This total does not clear when resetting the trip data.

Off Course: The distance to the left or right by which you have strayed from the original path of travel. You must be navigating for this data to appear.

Pointer: An arrow points in the direction of the next waypoint or turn. You must be navigating for this data to appear.

Speed: The current rate of travel.

Speed Limit: The reported speed limit for the road. Not available in all maps and in all areas. Always rely on posted road signs for actual speed limits.

Speed - Maximum: The highest speed reached since the last reset.

Speed - Moving Avg.: The average speed while moving since the last reset.

Speed - Overall Avg.: The average speed while moving and stopped since the last reset.

Stopwatch Timer: The stopwatch time for the current activity.

Sunrise: The time of sunrise based on your GPS position.

Sunset: The time of sunset based on your GPS position.

Temperature: The temperature of the air. Your body temperature affects the temperature sensor.

Temperature - Water: The temperature of the water. Your device must be connected to a NMEA 0183 device capable of acquiring the water temperature.

Time of Day: The current time of day based on your current location and time settings (format, time zone, daylight saving time).

Time To Destination: The estimated time remaining before you reach the destination. You must be navigating for this data to appear.

Time To Next: The estimated time remaining before you reach the next waypoint in the route. You must be navigating for this data to appear.

To Course: The direction in which you must move to get back on the route. You must be navigating for this data to appear.

Total Lap: The stopwatch time for all the completed laps.

Track Distance: The distance traveled for the current track.

Trip Odometer: A running tally of the distance traveled since the last reset.

Trip Time: A running tally of the total time spent moving and not moving since the last reset.

Trip Time - Moving: A running tally of the time spent moving since the last reset.

Trip Time - Stopped: A running tally of the time spent not moving since the last reset.

Turn: The angle of difference (in degrees) between the bearing to your destination and your current course. L means turn left. R means turn right. You must be navigating for this data to appear.

Velocity Made Good: The speed at which you are closing on a destination along a route. You must be navigating for this data to appear.

Vertical Dist to Dest: The elevation distance between your current position and the final destination. You must be navigating for this data to appear.

Vertical Dist to Next: The elevation distance between your current position and the next waypoint in the route. You must be navigating for this data to appear.

Vertical Speed: The rate of ascent or descent over time.

Vertical Speed To Dest: The rate of ascent or descent to a predetermined altitude. You must be navigating for this data to appear.

Waypoint At Dest: The last point on the route to the destination. You must be navigating for this data to appear.

Waypoint At Next: The next point on the route. You must be navigating for this data to appear.

Heart Rate Zone Calculations

Zone	% of Maximum Heart Rate	Perceived Exertion	Benefits
1	50–60%	Relaxed, easy pace, rhythmic breathing	Beginning-level aerobic training, reduces stress
2	60–70%	Comfortable pace, slightly deeper breathing, conversation possible	Basic cardiovascular training, good recovery pace
3	70–80%	Moderate pace, more difficult to hold conversation	Improved aerobic capacity, optimal cardiovascular training
4	80–90%	Fast pace and a bit uncomfortable, breathing forceful	Improved anaerobic capacity and threshold, improved speed
5	90–100%	Sprinting pace, unsustainable for long period of time, labored breathing	Anaerobic and muscular endurance, increased power

Index

- A**
 - accessories 7, 11
 - addresses, finding 4
 - adventures 3, 4
 - alarms
 - clock 6
 - marine 10
 - proximity 6
 - almanac
 - hunting and fishing times 6
 - sunrise and sunset times 6
 - altimeter 5, 10
 - ANT+ sensors 10
 - pairing 7
 - area calculation 6
 - Auto Lap 10
- B**
 - backlight 8, 11
 - barometer 5
 - BaseCamp 3, 12
 - battery 1, 11
 - installing 1
 - maximizing 8, 11
 - storage 11
 - Bluetooth technology 7
- C**
 - calendar 6
 - calibrating
 - altimeter 5
 - compass 4
 - chirp 6, 10
 - City Navigator 4
 - cleaning the device 11, 12
 - cleaning the touchscreen 12
 - compass 4, 5
 - navigating 4
 - settings 9
 - computer, connecting 12
 - countdown timer 6
 - course, pointer 5
 - customizing the device 8
 - cycling 7
- D**
 - dashboards 8, 9
 - data
 - storing 7
 - transferring 7, 12
 - data fields 8, 13
 - deleting
 - all user data 12
 - history 7
 - device
 - care 11
 - registration 11
 - resetting 12
 - display settings 8, 9
 - downloading, geocaches 5
- E**
 - elevation 2, 5
 - plot 5
- F**
 - files, transferring 5, 12
 - fitness 7, 10
- G**
 - Garmin Connect, storing data 7
 - Garmin Express 11
 - registering the device 11
 - updating software 11
 - geocaches 5, 6, 12
 - downloading 5
 - settings 10
 - GLONASS 9
- GPS 6, 9
- H**
 - heading setting 9
 - heart rate, zones 8, 14
 - history 7
 - sending to computer 7
 - home screen 1
 - HomePort 12
 - hunting and fishing times 6
- K**
 - keys 1
- L**
 - lifetime athlete 10
 - locations
 - editing 2
 - saving 2
 - locking, screen 8
- M**
 - man overboard (MOB) 5
 - map settings 8
 - maps 4, 8
 - data fields 8
 - navigating 2
 - optional 4
 - settings 8
 - updating 11
 - marine
 - alarms setup 10
 - settings 10
 - memory card 12
 - menu 1
 - microSD card 1, 12. See memory card
- N**
 - navigation 4, 5
 - compass 4
 - road 4
 - stopping 4
 - notifications 7
- O**
 - on-screen buttons 1
- P**
 - pairing
 - ANT+ sensors 7
 - smartphone 7
 - position format 10
 - power key 1
 - product registration 11
 - profiles 9, 10
 - proximity alarms 6
- R**
 - registering the device 11
 - resetting the device 11, 12
 - restoring, settings 11
 - routes 3
 - creating 3
 - deleting 3
 - editing 3
 - settings 9
 - viewing on the map 3
 - running 7
- S**
 - satellite signals 6
 - acquiring 4
 - screen 8
 - locking 8
 - settings 8–11
 - device 9
 - sharing data 6
 - Sight N' Go 5
 - smartphone 6
 - pairing 7
 - software, updating 11
 - specifications 11
- stopwatch 6
- storing data 12
- sunrise and sunset times 6
- system settings 9
- T**
 - tempe 13
 - temperature 13
 - time settings 10
 - time zones 10
 - timer 7
 - countdown 6
 - tones 9
 - touchscreen 1, 8
 - TracBack 2
 - tracks 1–3
 - archiving 2
 - settings 1, 9
 - transferring
 - files 3, 5, 6, 12
 - tracks 6
 - trip planner. See routes
 - troubleshooting 11, 12
- U**
 - unit ID 12
 - units of measure 10
 - USB
 - connector 1
 - disconnecting 12
 - mass storage mode 12
 - transferring files 12
 - user data, deleting 12
 - user profile 10
- V**
 - VIRB remote 7
- W**
 - water resistance 12
 - waypoints 2, 4
 - deleting 3
 - editing 2, 3
 - projecting 3
 - saving 2
 - Where To? 4

www.garmin.com/support



1800 235 822



+43 (0) 820 220230



+ 32 2 672 52 54



0800 770 4960



1-866-429-9296



+385 1 5508 272
+385 1 5508 271



+420 221 985466
+420 221 985465



+ 45 4810 5050



+ 358 9 6937 9758



+ 331 55 69 33 99



+ 39 02 36 699699



(+52) 001-855-792-7671



0800 427 652



0800 0233937



+47 815 69 555



00800 4412 454
+44 2380 662 915



+35 1214 447 460



+386 4 27 92 500



0861 GARMIN (427 646)
+27 (0)11 251 9800



+34 93 275 44 97



+ 46 7744 52020



+886 2 2642-9199 ext 2



0808 238 0000
+44 870 850 1242



+49 (0) 89 858364880
zum Ortstarif - Mobilfunk
kann abweichen



913-397-8200
1-800-800-1020

