

Scupper Valve

Provides a water exit for boats with self-bailing cockpits. Acetal construction. Accommodates 3875B thru-transom thru-hull connector (screw holes must be drilled for installation.) Diameter: 2-7/8". Use as a replacement valve for 3881 Thru-Transom Scupper. Caution: Plastic Thru-Hull Connectors are designed for installation above the water line only.

OEM Part #	Part #
3876-1	3876-3



3876

Thru-Transom with Scupper

- The rubber flapper opens to drain water out and closes to prevent backwash.
 - Acetal construction.
 - For 1-1/2" I.D. hose.
 - Installation Hole Size: 2"
 - Service Part Kit: Includes outer ring, rubber flapper, four SS screws
- Caution: Plastic Thru-Hull Connectors are designed for installation above the water line only.

Description	Dimensions	Max Hull Thickness	OEM Part #	Part #
Thru-transom with scupper	6-1/4" L x 2-7/8" dia.	3-1/8"	3881-1	—
Service Part Kit			3881Kit-1	—



3881

Thru-Hull with Strainer

Thru-hull connector with strainer prevents clogging of the aerator pump. Strainer attaches to threads that extend beyond external retaining nut. Acetal construction. Caution: Do not use strainer as a thru-hull connector nut replacement.

Hose Size	Max Hull Thickness	Installation Hole Size	OEM Part #	Part #
3/4" I.D.	1-7/16"	1-1/16" to 1-1/8"	3886-1	3886-3



3886

Drains, Drain Plugs & Tubes

Mesh Strainer/Drain Filter

Durable strainers to prevent debris from clogging baitwell drains and aerator pumps. Two types of construction: formed stainless steel wire mesh molded into black PVC plastic base or acetal plastic.

Caution: Aerator pump must be secured with aerator attachment nut prior to installing strainer.

Type	Thread	Application	OEM Part #	Part #
Stainless Steel mesh	7/8"- 9 UNC2-B	Fits 3877-1 thru-hull	11524-1	11524-3
	3/4"-14 NPSM	Fits 3/4" aerator inlet and 3886-1 thru-hull	4232-1	4232-7
Molded plastic	3/4"-14 NPSM	Fits aerator inlet and 3886-1 thru-hull	3885-1	3885-3



11524



3885