

# STEELIE®

## CAR MOUNT KIT

**APPLY MOBILE SOCKET, WITH THE INCLUDED 3M™ VHB™ FOAM ADHESIVE, TO SURFACES 60°F (16°C) OR HIGHER.**

**STEELIE USES HIGH PERFORMANCE 3M™ VHB™ FOAM ADHESIVE. FOR BEST RESULTS, FOLLOW THESE INSTRUCTIONS CAREFULLY.**

### PHONE SOCKET INSTALLATION INSTRUCTIONS:

THE PHONE SOCKET CAN BE ADHERED DIRECTLY TO THE BACK OF MOST PHONES AND HARD CASES.

**FOR IPHONE 4/4S WITHOUT A CASE (OR ANY PHONE WITH A GLASS BACK),** FIRST PLACE THE ENCLOSED CLEAR DISK ONTO THE BACK OF PHONE AND THEN ADHERE PHONE SOCKET TO THE CLEAR DISK (FOLLOWING INSTRUCTIONS BELOW).

**THE PHONE SOCKET CANNOT BE ADHERED TO A SOFT, FLEXIBLE PHONE CASE.** TO USE THE PHONE SOCKET WITH A SOFT, FLEXIBLE CASE, CUT A HOLE IN THE CASE AND ADHERE PHONE SOCKET DIRECTLY TO THE PHONE (FOLLOWING INSTRUCTIONS BELOW).

1. CLEAN THE BACK OF THE PHONE/ PHONE CASE WITH THE ENCLOSED ALCOHOL PAD. LET DRY. DO NOT USE HOUSEHOLD CLEANERS.
2. REMOVE THE ADHESIVE BACKING FROM THE PHONE SOCKET.
3. POSITION THE PHONE SOCKET IN THE CENTER OF THE DEVICE AND FIRMLY PRESS INTO PLACE.

### BALL MOUNT INSTALLATION INSTRUCTIONS:

1. BEFORE REMOVING ADHESIVE BACKING, POSITION THE BALL MOUNT IN A FEW DIFFERENT PLACES ON DASH. FOR BEST RESULTS, ATTACH PHONE TO BALL MOUNT AND CHOOSE DESIRED POSITION ON DASH.
2. CLEAN THE CHOSEN AREA WITH THE ENCLOSED ALCOHOL PAD. DO NOT USE HOUSEHOLD CLEANERS.
- 3A. **IF THE BALL MOUNT WILL BE INSTALLED ONTO A SOFT TEXTURED SURFACE SUCH AS A VINYL CAR DASH OR ON RUBBER,** FIRST APPLY THE ENCLOSED 3M PRIMER TO THE SURFACE. SQUEEZE THE 3M PRIMER STICK AT THE DOT TO WET THE FELT TIP. RUB THE PRIMER ONLY ONTO THE IMMEDIATE AREA WHERE THE BALL MOUNT WILL BE PLACED AND ALLOW THE PRIMER TO DRY FOR 5 MINUTES. PEEL THE ADHESIVE BACKING FROM THE BALL MOUNT AND PRESS FIRMLY INTO PLACE.
- 3B. **IF THE BALL MOUNT WILL BE INSTALLED ONTO A HARD SURFACE SUCH AS HARD PLASTIC, METAL, OR WOOD VENEER,** PEEL THE ADHESIVE BACKING FROM THE BALL MOUNT AND PRESS FIRMLY INTO PLACE.
4. WAIT AT LEAST 30 MINUTES FOR ADHESIVE TO BOND BEFORE USING THE STEELIE. DON'T PULL ON THE BALL MOUNT UNTIL THE ADHESIVE IS FULLY CURED (AFTER 24 HOURS).



## MAGNET WARNING—PLEASE READ

THE STEELIE CONTAINS A STRONG MAGNET. THE MAGNET WILL NOT DAMAGE PHONES OR TABLETS WITH SOLID STATE HARD DRIVES (INCLUDING IPHONES, IPADS, ETC.) AS APPLE HAS SHOWN WITH THE IPAD SMARTCOVERS.

HOWEVER, MAGNETS CAN DAMAGE SENSITIVE OBJECTS INCLUDING PACEMAKERS, COMPUTER HARD-DRIVES, FLOPPY DISKS, CREDIT CARDS, MAGNETIC I.D. CARDS, CASSETTE TAPES, VIDEO TAPES AND OTHER SIMILAR ITEMS. CERTAIN TELEVISIONS, VCRS, COMPUTER MONITORS AND OTHER CRT DISPLAYS MAY ALSO BE AFFECTED. NITE IZE ASSUMES NO LIABILITY FOR DAMAGE TO SUCH OBJECTS.

KEEP OUT OF REACH OF CHILDREN. MAGNETS CAN BE HARMFUL IF SWALLOWED.