



Universal Wireless Charge Receiver Patch

Designed and engineered by the outdoor technologies experts Scanstrut, the new ROKK wireless charging receiver patches are wireless charge ready! Simply plug the Mirco USB or Lightning charge patch into your phones charging port, place on the back of the phone and then clip on your phone case over the top. Your phone is now ready to be charged by any of the 12/24V ROKK wireless charger range or any other Qi-certified charging product.



Part Number	Connector	Description
SC-CW-RCV-LU	Lightning	Universal Lightning wireless charge receiver patch for iPhone
SC-CW-RCV-MU	Micro USB	Universal Micro USB wireless charge receiver patch

For the most direct access to Scanstrut technical support and your local sales representative visit

usasales@scanstrut.com **www.scanstrut.com** (860) 308-1416, option 2