

HOW TO MEASURE FOR REPLACEMENT STEERING CABLES

Part numbers for ordering:
M66 XLL LL = Length of cable
M86 XLL LL = Length of cable
M68 XLL LL = Length of cable
M67 XLL LL = Length of cable
M90 XLL LL = Length of cable

D = Conduit length



ORDER LENGTH: "D" dimension + 22" and round up to the next whole foot

Example: $D = 120'' + 22'' = 142''$ (11'8"). Round up to 12 ft