

PCX Mirror Installation Instructions

Tools Needed: Allen Wrench

- 1. Detach the mirror arm (1) from the mirror pivot (3) by turning the knob (2) counter-clockwise.
- 2. Postion base (5) onto desired location and determine which set screws will best fit the boat.
- 3. Apply small bead of thread locker to the set screws.
- Attach the base using chosen set screws with Allen Wrench (not included).
- 5. Loosen nut (3) in mirror base (4) with supplied wrench.
- 6. Rotate the mirror pivot (3) to desired location and tighten nut.
- 7. Attach the spacer (7) to mirror housing (6) as shown.
- 8. Attach the mirror housing (6) to arm (1) as shown using knob (8).
- 9. Attach the arm (1) to pivot (4) using knob (2).
- Once you have the mirror where you want, tighten the knob (2) until the arm is secure.

Contents of box:

- 1. Mirror Bracket Assembly
- 2. Pair of 1-1/4" Set Screws
- 3. Pair of 3/4" Set Screws
- 4. Thread Locker
- 5. VR-100 PRO Mirror
- 6. Washer



1010 Larson Dr. | Oak Ridge, TN 37830 865.425.0600 | support@protomet.com