

AC PLUG PORT INSTRUCTIONS

CH-PLUG-12-AC_EA • CH-PLUG-6-AC_EA • CH-PLUG-RECEPT_EA

Installation Tools:

- 1/8" Drill Bit
- 2" Hole Saw
- Electric Drill

Included Hardware:

- (1) AC Plug Port Assembly
- (4) Mounting Screws
- (1) Drill Template
- (2) Assembly Bolts

IMPORTANT!

- · Only compatible with Power-Pole extension cords or the AC cord from the CHARGE.
- · Always use cover when not in use.




Drilling Instructions

- STEP 1: Mounting location: at least 21" away from all batteries, fuel lines, & integral support structures.
- **STEP 2:** Align template with mounting location & drill a pilot hole for the hole saw using a 1/8" drill bit. If installing into a gel-coat, use the template to drill four pilot holes for mounting screws.
- STEP 3: Drill mounting hole with a 2" hole saw.

Installation Instructions

Mounting Surface

 Route cord from CHARGE to mounting hole. Insert cord through silicone cap ring and into plug port.



Insert assembled plug port into mounting hole and tighten the (4) mounting screws snua.

2 Clamp cord into place.



9010 Palm River Road, Tampa, Florida 33619 • phone 813.689.9932 fax 813.689.8883 • power-pole.com | Power-Pole is a registered trademark of JL Marine Systems, Inc. © Copyright 2021 JL Marine Systems, Inc. All Rights Reserved.