Power Pux

The Worlds First Power Supplied Trolling Motor Quick Release Bracket

What you will need

- 1.8 Gauge insulated Wire. (Enough to reach from the batteries to the bow Puck)
- 2. Your own stainless hardware for mounting the Puck to the deck. (Style depends on the mounting method that you choose based on the boat design and composition.)
- 3. BoatLife LifeSeal Caulking
- 4. Acetone
- 5. Clean Rags
- 6. Lead Pencil
- 7. Wire cutters
- 8. Wire Crimping Tool
- 9. Heat gun or small Butane Torch
- 10. ¾" inch Hole Saw or Spade Bit

NOTE: Some boat designs may require a Fish Tape or similar device to pull wires through inaccessible compartments.