USER'S MANUAL

B62ABT

6.5" 2-WAY AMPLIFIED MARINE GRADE
ROLL CAGE/WAKETOWER SPEAKER PODS
FEATURES BLUETOOTH® CONTROLLER AND BUILT-IN AMPLIFIER







Thank you for purchasing this




B62ABT All Terrain Sound System

Please read through these instructions carefully so you will know how to operate your model properly.

After you have finished reading the instructions, keep this document in a safe place for future reference.

THIS PACKAGE CONTAINS

- 2- B62ABT Marine Waketower Speaker System (1 Active + 1 Passive)
- 1- Bluetooth Multi-Function Controller
- 1- Handlebar Mounting Kit for Bluetooth Controller
- 1- Mounting Bracket Kit
- 1- Power Wire Harness Kit
- 2- Security Rope
- 1- User Manual Quick Start Guide / Poster
- 1- Warranty Card















INFORMATION TO THE USER

Bluetooth°

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks is under license.

Other trademarks and trade names are those of their respective owners.

INFORMATION TO THE USER



FCC COMPLIANCE STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of this device.

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter. The Bluetooth antenna cannot be removed (or replaced) by user. This equipment complies with FCC/ IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment has very low levels of RF energy that it deemed to comply without maximum permissive exposure (MPE) evaluation. But it is desirable that it should be installed and operated keeping the radiator at least 20 cm or more away from person's body (excluding extremities: hands, wrists, feet and ankles). Alteration or modifications carried out without appropriate authorization may invalidate the user's right to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- □ Relocate or reorient the receiving antenna.
- $\hfill \square$ Increase the separation between the equipment and receiver.
- □ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- □ Consult the dealer or an experienced radio/TV technician for help.



CAUTION!!

BEFORE YOU START



IMPORTANT SAFETY PRECAUTIONS

- Do not operate mobile equipment while driving a motorized vehicle safe driving and safety consideration of others should always be your highest priority.
- In the event you should notice smoke, strange noises or odor from this product, or any other abnormal signs, immediately turn off the power and consult your dealer or the nearest authorized *BOSS AUDIO* Service Center. Using this product in this condition may result in permanent damage to the system.
- Set your volume control at a low setting, then slowly increase the sound until you can hear it comfortably without distortion, or ear discomfort.
- BE SURE TO OBSERVE THE FOLLOWING GUIDELINES:
- Do not turn up the volume so high that you can't hear what's around you.
- Use caution or temporarily discontinue use in potentially hazardous situations.

INSTALLATION PRECAUTIONS

WARNING - Always consult a professional installer

- Do not attempt to install or service this product by yourself. Installation or servicing of this product by persons without professional training and experience in electronic equipment and motorized vehicle accessories may be dangerous and could expose you to the risk of electric shock, injury or other hazards
- Refer any repairs to a qualified **BOSS AUDIO SYSTEMS** Service Center
- The **B62ABT** can be powered from a vehicles cigarette lighter / auxiliary power port, or hard wired directly to the battery through an optional relay / accessory switch
- When wiring directly to the vehicles battery, be sure to disconnect the battery negative terminal wire before starting any wiring procedures, it is suggested that an optional fuse and fuse holder (not included) with minimum rating of **20 Amps** be in line with the positive battery terminal
- The ground cable length should not exceed 18 inches (See wiring diagram)
- The **B62ABT** has a weather resistant design, it should not be submerged in or under water under any circumstances
- Use only the installation parts provided with the B62ABT




CAUTION!! Using other mounting methods may void this warranty

GETTING STARTED




GETTING TO KNOW YOUR B62ABT MULTIFUNCTION CONTROLLER (MFC)



- 1 MFC MULTIFUNCTION CONTROLLER
- 2 BLUETOOTH INDICATOR LED(BLUE) / AUX-IN STATUS INDICATOR(RED)
- 3 3.5mm AUX-INPUT
- 4. PLAY/PAUSE / Press and hold for POWER ON
- 5 PREVIOUS TRACK / Press and hold for VOL -
- 6 NEXT TRACK / Press and hold for VOL + /
 - Warning tone while up to maximum volume in Bluetooth mode
- 7 Disconnect any paired Bluetooth device by pressing button for 4 seconds
- Clear any paired Bluetooth device in memory by pressing button for 10 seconds
- 9 Disconnect any paired Bluetooth device by turning off bluetooth in your device setting menu
- When power on, blue back lit button sparkles slowly for 30+ seconds to search for ex-paired device; after then button blue back lit turns to sparkle quickly for 9mins 30secs until it is powered off
- When Bluetooth devie is out of connection range and Bluetooth pairing is disconnected automatically, and then blue back lit button sparkles slowly for 1 min to look for ex-paired device, after then button blue back lit turns to sparkle quickly for 9mins until it is powered off
- 12 When operation voltage is lower than 9.5Volt, MFC gives warning tone
- MFC concludes tones of definition : Power On/Off , Bluetooth connection / Disconnection , Maximum volume, Lower voltage

BLUETOOTH OPERATION





PAIRING & DISCOVERING A NEW BLUETOOTH CONNECTION

1) Power on the **B62ABT** by pressing and holding down the **Play/Pause** multifunction

button for 3 seconds, the blue LEDs will start to flash, signalling that the B62ABT is now ready for Bluetooth pairing.

NOTE: You have 30 Seconds before you must restart this procedure over again.

2) Now that the **B62ABT** is in pairing mode:

ANDROID users:


- a. Go into the Settings Menu of your device
- b. Enter the Bluetooth Menu
- c. TURN ON Bluetooth and press SCAN
- d. "BOSS B62ABT" will now be displayed under AVAILABLE DEVICES
- e. Press "BOSS B62ABT" to get Bluetooth connected

iOS users:

- a. Go into the Settings Menu of your iOS device
- b. Enter the Bluetooth Menu
- c. TURN ON Bluetooth
- d. "BOSS B62ABT" will now be displayed
- e. Press "BOSS B62ABT" to get Bluetooth connected
- 3) If the BOSS B62ABT is not seen, repeat the above steps to refresh the "Device List"
- 4) When the connection is successful, you are now ready to stream music from your favorite media player to the **B62ABT**

BLUETOOTH / OPERATION






RECONNECTION

- 1) Power on the B62ABT and your last paired device Bluetooth.
- 2) The unit will now automatically reconnect
- 3) If your device was previously paired with the **B62ABT**, but it wasn't the last paired device:
 - a. Ensure no other devices are currently paired
 - b. Enter the Bluetooth Menu on your device being paired
 - c. "BOSS B62ABT" will display under AVAILABLE DEVICES
 - d. Choose the "BOSS B62ABT" to reconnect
- 4) If the device is out of range from the **B62ABT**, it will disconnect automatically:
 - a. To reconnect once device is back in range, press the button once
 - b. The **B62ABT** will now reconnect to the device

To avoid battery exhaustion, be sure to occasionally run the vehicles engine while using this product.
Using this product without running the engine can drain the battery.




MULTIFUNCTION CONTROLLER BLUETOOTH OPERATION

- 1) Press the PLAY/PAUSE once to start playing music or press the PLAY button from your device touch screen
- 2) To skip songs or advance, press the NEXT TRACK button
- 3) To select the previous song, press the ($||\zeta|$) **PREVIOUS TRACK** button

VOLUME CONTROL

- 4) To raise the volume, *Press and Hold* the *VOL* + button 2 ~ 3 seconds
- 5) To lower the volume, **Press and Hold** the (||) **VOL -** button 2 ~ 3 seconds



MULTIFUNCTION CONTROLLER AUX-IN OPERATION

- 1) Power on the **B62ABT** by pressing and holding down the PLAY/PAUSE multifunction button for 3 seconds
- 2) Disconnect any paired *Bluetooth* device by turning off *Bluetooth* in your devices *Settings Menu*
- 3) Connect the integrated 3.5mm $\it AUX-IN$ cable located on right side of the MFC to your devices headphone jack

VOLUME CONTROL

- 4) To raise the volume, **Press and Hold** the **VOL** + button 2 ~ 3 seconds
- 5) To lower the volume, **Press and Hold** the \bigcirc **VOL -** button 2 ~ 3 seconds


To avoid potential short system, be sure to discontant applies before install the property of the property of

To avoid potential shorts in the electrical system, be sure to disconnect the (–) battery cable before installation. Use this unit with a 12-Volt battery and negative grounding only. Failure to do so may result in a fire or malfunction.



When replacing the fuse, be sure to only use a fuse of the rating specified on this product. To avoid short-circuiting, cover any disconnected leads with insulating tape. It is especially important to insulate any unused wires, which if left uncovered may cause a short circuit. When connecting other devices to this product, refer to the manual for the product to be connected. The black cable is ground, make sure to connect the ground wire first. Ensure that the ground wire is properly connected to metal parts of the vehicles body frame or direct to the battery if your vehicle does not have a grounded chassis frame. The ground wire of this unit power amp and a second powered system must be connected to the frame separately with different screws. If the screw for the ground wire loosens or falls out, it could result in fire or malfunction.

SPEAKER MOUNTING SUGGESTIONS






TOOLS NEEDED:

- 12mm Socket, Wrench or Pliers
- 6mm Allen Wrench

Hand Tools Required:


- 3/16" Hex Key and Bit Socket
- 5/32" Hex Key and Bit Socket
- Torque Wrench (in/lbs or nM)
- Thread Lock Compound

STEP 1: Removing the top half of clamp



Using the 3/16" Hex key, remove the top clamp bolts, and note the Caution labels for correct torque settings later.

STEP 2: To adjust speaker position



If speaker position is not to be changed, remove the screws and apply threadlocker compound. Using the 5/32" hex bit socket, torque swivel screws to 44 in/lbs (5nM).

To change the speaker position, use the 5/32" hex key remove the screws.


Note: the orientation of the screws must remain in the 12 and 6 o'clock positions after moving the bottom clamp to the desired position.

STEP 3: Swivel screws




Apply thread locker compound to the screws. Tighten the screws using the 5/32" Hex bit socket and torque wrench to 44 in/lbs (5nM).

STEP 4: Securing clamp bolts



Using the correct rubber pads (labeled for O.D.) install on both top and bottom half of clamps. Apply thread locker compound to the bolts. Hand tighten the bolts evenly (both sides should have the same spacing between bolts). Using the 3/16" Hex bit socket, set the torque wrench to 65 in/lbs (7nM).

STEP 5: Security rope



Loop the rope around the base of the clamp and bar, secure with the supplied hardware.

12V WIRE HARNESS CONNECTION SQUEEZE MICON MICHAEL MARKET MICON MICHAEL MARKET MICHAEL MARKE

BLUETOOTH


- · Version: 4.0 w/ EDR
- A2DP
- Range: 33ft (10m)

SPEAKERS


- Impedance: 4Ω
- · Magnet: Ferrite
- Cone Type: Injected Polypropylene Cone with Butyl Rubber Surround
- Tweeter Size: 1" PEI DOME

AMPLIFIER

- · Maximum Output Power: 750 Watts
- Input impedance: 10kΩ
- Frequency Response: 45Hz-20kHz
- · Low Battery Shut Off
- · Standby Current 0.5mA



SPECIFICATIONS



GENERAL

- Operational Power: 12VDC (10-16V allowable)
- MAX Current Draw: 7.8 A
- · Replacement Fuse: 10A AGC TYPE
- · Color: Black
- Weight: 13.91lbs / 6.31Kg
- Dimensions cm WxHxD: 21.7 x 28.4 x 23.8
- Dimensions Inches WxHxD: 8.54 x 11.18 x 9.37

SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE



Like us on Facebook!

BE THE FIRST TO SEE NEW PRODUCTS!



SHARE YOUR
BOSS AUDIO SYSTEM PHOTOS!

WATCH FOR CONTEST GIVEAWAYS AND WIN PRIZES!

USER'S MANUAL

B62ABT

6.5" 2-WAY AMPLIFIED MARINE GRADE
ROLL CAGE/WAKETOWER SPEAKER PODS
FEATURES BLUETOOTH® CONTROLLER AND BUILT-IN AMPLIFIER



BOSS Audio Systems 3451 Lunar Court • Oxnard, CA 93030

www.bossaudio.com 800-999-1236 US Toll-free 805-751-4853 Customer Service

Tech Support: www.bossaudio.com/support/technical-support



0619

iPod® and iPhone® are trademarks of Apple, Inc. registered in the U.S. and other countries.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by BOSS Audio Systems is under license. Other trademarks and trade names are those of their respective owners.