

Outback™ Inflatable SUP Board Owner's Manual



www.ravesports.com

Table of Contents

Warnings.....	3
Safety.....	4
Equipment	5
Set up.....	5
How to use SUP Board.....	6
Deflation.....	6
Cleaning, storage and repair	7
Limited 1 year warranty	9

Water sports can be safe and fun for all levels of enthusiasts. The Owner’s Manual is presented to enhance your enjoyment of the sport. It is intended to alert you to some of the potentially dangerous conditions that can arise in all water sports.

Copyright ©

All rights reserved. No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopy, recording, or any information storage and retrieval system, without permission in writing from the publisher. Requests should be mailed to RAVE Sports, 3325 Labore Road, Saint Paul, Minn 55110

⚠ WARNING

200 LBS MAXIMUM RIDER WEIGHT

⚠ WARNING

PADDLE BOARDING CAN BE VERY DANGEROUS AND PHYSICALLY DEMANDING.

PARTICIPATING IN PADDLE BOARDING MAY INVOLVE SERIOUS INJURY OR DEATH.

PADDLE BOARDING REQUIRES GOOD BALANCE AND CORE STRENGTH.

BE CAUTIOUS IF USING IN SHALLOW WATER. FALLING IN SHALLOW WATER MAY RESULT IN SERIOUS BODILY INJURY OR PARALYSIS.

TO AVOID SEVERE BODILY INJURY DO NOT USE NEAR DOCKS, PILINGS, PIERS OR OTHER HARD OBSTRUCTIONS.

ALWAYS USE CAUTION WHEN USING THIS PRODUCT. DO NOT ACT IN A CARELESS MANNER WHEN USING THIS PRODUCT. MISUSE OF THIS PRODUCT COULD RESULT IN SERIOUS INJURY OR DEATH.

Product safety and warnings

To reduce the risk of injury or death using this paddle board, follow these guidelines:

- Do not exceed the weight capacity limitations.
- Always wear a coast guard approved personal flotation device.
- Do not go paddle-boarding in harsh weather or in water conditions that might affect your ability to return to shore or steer the board.
- Adult supervision required when a minor is using the board.
- Never consume alcohol or any other substance that may impair your coordination, judgment, or ability to safely paddle the board.
- Never use this board beyond your skills or ability.
- Do not use this product after sunset or before sunrise or with poor lighting.
- Check local laws and regulations regarding proper and safe use of this product.
- Dress accordingly for weather conditions. Cold water and/or cold weather can result in Hypothermia.
- Never paddle alone.
- Do not paddle in flood conditions.
- Be aware of appropriate river water levels, tide changes, dangerous currents, weather changes and strong off shore winds.
- This product is designed for flat water use. Do not use in surf.

INCLUDED IN THIS PRODUCT:

- 1- Inflatable SUP Board
- 1- High Pressure Pump with Gauge
- 1- Carrying bag
- 1- Adjustable SUP Paddle
- 3- Fins and Attachment Screws
- 1- Repair kit

Set Up

1. Unfold product on flat ground making sure there are no sharp objects underneath that might puncture the product.
2. Inflate
 - Locate valve at back of board and unscrew cap.
 - A special inflation adaptor is included with pump. Simply lock the adaptor onto the end of the inflation hose and insert into the valve body. Turn $\frac{1}{4}$ turn to lock in place.

NOTE: This inflation adaptor will automatically open the valve when inserted and will close the valve when removed. You do not need to manually open/close the valve when using this special adaptor.



- Make sure gauge and hose is on the inflation side of pump

- Inflate SUP board to 10-12 psi. (DO NOT GO OVER 14 PSI)

3. Attach Fins

- Attachment of fins can be done before or after the inflation process.
- Insert front of fin into slot and pull backwards to hook in place
- Secure with screws.




Properly Holding the Paddle

Blade should be facing forward for Performance SUP paddle..

Using the Board

- Start on your knees and push up to feet while centered on the board.
- Feet should be shoulder width apart with bent knees.
- Face forward with shoulders back.
- Hold paddle at the T-Handle and approximately 2 feet down on the shaft.
- To turn on the SUP board, paddle on the opposite side you desire to turn.



Deflation

1. Remove fins from bottom of board.
2. Open valve to release air.

3. Use deflation side of pump to rapidly and completely evacuate the air in the SUP board.
4. Fold board starting at front and working towards valve.

(ENSURE PRODUCT IS CLEAN AND DRY BEFORE FOLDING AND STORING)

NOTE: DO NOT ROLL BOARD.

5. Use strap to hold board together and place in carrying bag.
6. Store in carrying bag. Paddle goes in the long side pouch. Pump goes into shorter pouch.



Cleaning and Storage

- When the inflatable product is not being used, we recommend that you store it in a covered, shaded area. This will help protect it against ultraviolet (UV) rays and extend the life of the product.
- Clean the inflatable completely with a mild soap and fresh water. NEVER USE PETROLEUM BASED PRODUCTS OR SOLVENTS FOR CLEANING.

- Product should be completely dry and remain dry while stored.
- Fold the product loosely and place in the vented carrying bag.
- Store in a cool, dry location. Do not store product directly on concrete surface. Place mothballs around stored inflatable to keep mice and insects away.
- Secure the product to prevent unauthorized or unsupervised use.
- Do not leave board inflated in direct sunlight for long periods of time when not in use

Repairs

For Minor Holes or Tears:

- Inflate SUP board and locate the leak by spraying the board with soapy water. Bubbles will appear where there is a leak.
- Determine the hole size and cut a circular patch $\frac{1}{2}$ - 1 inch wider than the hole.
- Deflate the product and clean the patch and area around the hole with rubbing alcohol. Let dry completely.
- Peel off paper back from patch, apply repair patch to area and work out any air bubbles from beneath the patch.
- Apply weight to the patched area for one hour before re-inflating

RAVE Sports® Limited One Year Warranty

The Limited One Year Warranty set forth below is provided by RAVE Sports®, A Revel Match, LLC company with respect to product(s) purchased and used in the United States and Canada.

RAVE Sports'® product(s), when delivered to you in a new condition in original container, are warranted against defects in material or workmanship for a period of one (1) year from the date of original purchase when used in a non-commercial application. Product(s) used in a commercial application are warranted against defects or workmanship for a period of six (6) months from the date of original purchase. Defective product(s) returned to RAVE Sports® or an authorized service location and are proven to be defective upon inspection, will be repaired or exchanged for a new product(s) or part(s) at a prorated value where applicable. The warranty period for any replacement product shall begin upon shipment of the same, but shall in no event exceed the warranty period of the defective product.

When returning any product under this Limited One Year Warranty, you must first contact RAVE Sports® to obtain a return authorization number. The product must be packaged in its original carton or comparable packaging with a copy of the bill of sale (or invoice of purchase), together with a complete explanation of the problem. Shipping charges, if any, must be prepaid. Products covered by this Limited One Year Warranty will be returned to you without charge by RAVE Sports®.

This Limited One Year Warranty covers all defects encountered in normal use of the product and **does NOT** apply in the following cases:

- a) Loss or damage due to abuse, mishandling, alteration, accident
- b) Failure to follow operating, maintenance, or storage instructions
- c) Service by a party other than RAVE Sports'® authorized service personnel
- d) Any acts of God including storm and animal damage
- e) The product has had its serial number(s) or dating altered or removed
- f) Normal wear and tear which includes sun damage and other normal weathering of the product

No implied warranty (or condition), including any implied warranty (or condition) of merchantability or fitness for a particular purpose, applies to the product after the applicable period of express warranty stated above, and no other express warranty or guaranty, except as mentioned above, given by any person, firm, or corporation with respect to the product shall bind RAVE Sports®. Some states or provinces do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

RAVE SPORTS® SHALL NOT BE LIABLE FOR LOSS OF REVENUE OR PROFIT, FAILURE TO REALIZE SAVINGS OR OTHER BENEFITS, OR FOR ANY OTHER SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT REGARDLESS OF THE LEGAL THEORY ON WHICH THE CLAIM IS BASED, AND EVEN IF RAVE SPORTS® HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. NOR SHALL RECOVER ANY KIND AGAINST RAVE SPORTS® BE GREATER IN AMOUNT THAN THE PURCHASE PRICE OF THE PRODUCT SOLD BY RAVE SPORTS® AND CAUSING THE ALLEGED DAMAGE.

WITHOUT LIMITING THE FOREGOING, YOU ASSUME ALL RISK AND LIABILITY FOR LOSS, DAMAGE OR INJURY TO YOU AND YOUR PROPERTY AND TO OTHERS AND THEIR PROPERTY ARISING OUT OF THE USE, MISUSE, OR INABILITY TO USE ANY PRODUCT SOLD BY RAVE SPORTS® NOT CAUSED DIRECTLY BY THE NEGLIGENCE OF RAVE SPORTS®. SOME STATES OR PROVINCES DO NOT ALLOW EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS LIMITED 1 YEAR WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL PURCHASER OF ANY PRODUCT, OR THE PERSON FOR WHOM IT WAS PURCHASED AS A GIFT.

This Limited One Year Warranty gives you specific legal rights. To the extent that such rights cannot be disclaimed under applicable law, this limited warranty does not affect such rights.

This page intentionally left blank.



WWW.RAVESPORTS.COM

RAVE Sports
A Revel Match, LLC Company
3325 Labore Road
Saint Paul, MN 55110
800.659.0790

November 2013