

RUGGED FINGER-GRIP HOLDER ASSEMBLY INSTRUCTIONS

PARTS INDEX

- A. BACK PLATE FOR HOLDER (QTY 1)
- B. TOP AND BOTTOM SUPPORTS (QTY 2)
(CAN BE REMOVED FOR LARGER DEVICES)
- C. 3 LENGTHS OF FINGER GRIPS (QTY 4 EACH)
- D. VINYL END CAPS (QTY 4)
- E. #8-32 STST NYLOCK NUT THIN (QTY 8)
- F. #8-32 X 3/8" MACHINE SCREW (QTY 6)
- G. #8-32 X 5/8" MACHINE SCREW (QTY 2)
- H. #8-32 X 3/4" MACHINE SCREW (QTY 2)

SHORT FINGER




Max Depth: 0.75"
Min Width: 1.25"
Max Width: 3.0"

MEDIUM FINGER

Max Depth: 1.25"
Min Width: 1.5"
Max Width: 3.5"

LONG FINGER

Max Depth: 1.6"
Min Width: 2.25"
Max Width: 3.5"



1. SELECT APPROPRIATE FINGER GRIPS BASED ON DIMENSIONS OF YOUR DEVICE.
2. ATTACH (B) SUPPORTS TO TOP AND BOTTOM OF (A) BACK PLATE USING (F) SCREWS AND (E) NUTS. DO NOT TIGHTEN SCREWS YET.
3. ATTACH FINGER GRIPS USING (F) SCREWS AND (E) NUTS. DO NOT TIGHTEN SCREWS YET.
4. ATTACH (D) VINYL CAPS TO FINGER GRIPS. CUT ENDS IF NEEDED.
5. PLACE DEVICE IN HOLDER AND SLIDE FINGER GRIPS AGAINST DEVICE UNTIL FIRM.
6. REMOVE DEVICE. TIGHTEN ALL SCREWS WHERE APPROPRIATE.

USE (G) OR (H) SCREWS AND 2 (E) NUTS TO SECURE HOLDER TO YOUR RAM MOUNT

National Products, Inc. 8410 Dallas Ave S. Seattle, WA 98108, (206)-763-8361 www.ram-mount.com



RMR-INS-UN4

RUGGED FINGER-GRIP HOLDER ASSEMBLY INSTRUCTIONS

PARTS INDEX

- A. BACK PLATE FOR HOLDER (QTY 1)
- B. TOP AND BOTTOM SUPPORTS (QTY 2)
(CAN BE REMOVED FOR LARGER DEVICES)
- C. 3 LENGTHS OF FINGER GRIPS (QTY 4 EACH)
- D. VINYL END CAPS (QTY 4)
- E. #8-32 STST NYLOCK NUT THIN (QTY 8)
- F. #8-32 X 3/8" MACHINE SCREW (QTY 6)
- G. #8-32 X 5/8" MACHINE SCREW (QTY 2)
- H. #8-32 X 3/4" MACHINE SCREW (QTY 2)

SHORT FINGER



Max Depth: 0.75"
Min Width: 1.25"
Max Width: 3.0"

MEDIUM FINGER

Max Depth: 1.25"
Min Width: 1.5"
Max Width: 3.5"

LONG FINGER

Max Depth: 1.6"
Min Width: 2.25"
Max Width: 3.5"



1. SELECT APPROPRIATE FINGER GRIPS BASED ON DIMENSIONS OF YOUR DEVICE.
2. ATTACH (B) SUPPORTS TO TOP AND BOTTOM OF (A) BACK PLATE USING (F) SCREWS AND (E) NUTS. DO NOT TIGHTEN SCREWS YET.
3. ATTACH FINGER GRIPS USING (F) SCREWS AND (E) NUTS. DO NOT TIGHTEN SCREWS YET.
4. ATTACH (D) VINYL CAPS TO FINGER GRIPS. CUT ENDS IF NEEDED.
5. PLACE DEVICE IN HOLDER AND SLIDE FINGER GRIPS AGAINST DEVICE UNTIL FIRM.
6. REMOVE DEVICE. TIGHTEN ALL SCREWS WHERE APPROPRIATE.

USE (G) OR (H) SCREWS AND 2 (E) NUTS TO SECURE HOLDER TO YOUR RAM MOUNT

National Products, Inc. 8410 Dallas Ave S. Seattle, WA 98108, (206)-763-8361 www.ram-mount.com



RMR-INS-UN4