



# Aftermarket New Product Bulletin #2 Fall 2016+

## NEW Two-Piece Tactile Switch Kit Introduction and Installation Sheet

FOR DEALERS & CONSUMERS WHO CAN NOT USE THE LONGER INTEGRATED SWITCH DUE TO SPACE LIMITATIONS BEHIND THE CONSOLE



LENCO ESTIMATES TO START SHIPPING THIS NEW SWITCH KIT TO AFTERMARKET CUSTOMERS SEPTEMBER 1, 2016

### NEW LED Indicator Tactile Switch Kit Single

12 & 24-Volt Single Actuator Systems - 123SC-V2

This LED tactile switch kit has a shortened bezel for consoles which require less depth to mount. Functionality is built into the externally mounted control box and must be mounted separately.

Part# 15270-001 (shown)



Available kit for this series:

Part#	Description
15270-001	LED Indicator Two-Piece Tactile Switch Kit with Pigtail for Single Actuator Systems

Replacement parts for above kit:

30343-001	Replacement Key Pad - LED
30340-001	Replacement Control Box - LED
30140-001D	Replacement Power Pigtail - 36" (91.44 cm)

### NEW LED Indicator Tactile Switch Kit Dual

12 & 24-Volt Dual Actuator Systems - 123DR-V2

This LED tactile switch kit has a shortened bezel for consoles which require less depth to mount. Functionality is built into the externally mounted control box and must be mounted separately.

Part# 15271-001 (shown)




Available kit for this series:

Part#	Description
15271-001	LED Indicator Two-Piece Tactile Switch Kit with Pigtail for Dual Actuator Systems

Replacement parts for above kit:

30343-001	Replacement Key Pad - LED
30342-001	Replacement Control Box - LED
30140-202D	Replacement Power Pigtail - 72" (182.88 cm)


### Key Pad Dimensions & Installation Instructions



See the Lenco Marine owners manual for complete key pad and control box mounting instructions.  
[lencomarine.com/ownersmanual](http://lencomarine.com/ownersmanual)

Align the center bit of a 2 1/16" (52.39 mm) hole saw with the cross hairs in the center of the desired mounting area and drill straight down through the console, providing additional clearance for switch and electrical connection. Insert the switch into the console cutout hole then tightly screw the Bezel Locknut clockwise onto the backside of the key pad. Mount the control box within 24" (60.96 cm) of the tactile switch key pad.

**NOTE:**  
 The control box wire harness is 30" (76.2 cm) in length.



**ATTENTION: REPLACEMENT KEY PADS AND CONTROL BOXES FOR 2016 AND PRIOR SWITCHES ARE NOT COMPATIBLE WITH THE ABOVE NEW SWITCH KITS. PLEASE REFER TO OUR LENCO CATALOG AND / OR LENCOMARINE.COM FOR REPLACEMENT PARTS FOR OUR OLD-STYLE SWITCH KITS.**