




MOUNTING TEMPLATE



MOUNTING INSTRUCTIONS

DRILL BIT SIZE: 5/16" (.3125)

Use the corresponding key below to drill mounting holes on your boat to set up the MOVE PV with your preferred configuration. Your boat's edge must be positioned with enough clearance for the MOVE PV to deploy and operate correctly.



Standard configuration using provided **Quick Disconnect**



Optional configuration for mounting Move PV **directly to deck**