



Volvo® and Yamaha®



Optimus® (SEASTAR®) and Yanmar®



→ **Note:** for some systems, it is only possible to turn the rudder when the engine is in gear.


SIMRAD®

NAC™-D

INSTALLATION GUIDE



Dimensions



Compliance statements

Declarations

The relevant Declaration of Conformity is available on the following websites:
www.simrad-yachting.com

Europe

Navico declares under our sole responsibility that the product conforms with the requirements of:

- CE under EMC Directive 2014/30/EU

United States of America

→ **Note:** The user is cautioned that any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Australia and New Zealand

Navico declares under our sole responsibility that the product conforms with the requirements of:

- level 2 devices of the Radiocommunications (Electromagnetic Compatibility) standard 2017

Trademarks

®Reg. U.S. Pat. & Tm. Off, and ™ common law marks. Visit www.navico.com/intellectual-property to review the global trademark rights and accreditations for Navico Holding AS and other entities.