Model: IC9002 v02 Adult: Universal Body Weight: 110 - 330 lbs (50 - 150 kg) Height: 4'11" - 6'7" (1.5 - 2.0 m)

1

3

1

3

MUSTANG SURVIVAL ICE COMMANDER IMMERSION SUIT



DONNING INSTRUCTIONS 2 Remove footwear, Hood on, tip head, pull climb into suit. Use zipper down by toggle. pull tabs at back Secure zipper cover in of boot to assist place. donning. Pull on suit as coveralls. Use free hand to assist glove over opposite hand. **A**. Clip up harness **B.** While squatting, grab face flap (red tab) and pull forward to release excess air from the suit before operating in (1). Secure face flap over face or off the face by suit. Tighten crotch matching hook and loop fasteners (2). strap, leg straps, and wrist-strap В cinches to fit. **FOLDING INSTRUCTIONS** 2 В **A**. Lay the suit Grasp both boots out flat. Unzip at the top of the ankles, 2"-3" front zipper and unclip the safety above the top harness. of the boot, and fold them over. **B**. Turn suit over so zipper faces down. 4 Continue to: Insert folded suit into bag. **A**. Fold the ankles up to the waist. B. & C. Fold arms across the back and roll the whole suit up.



MUSTANG SURVIVAL ICE COMMANDER IMMERSION SUIT

MAINTENANCE

ANNUAL INSPECTION

- 1. Unpack the suit and lay it out flat, separating the inside buoyant liner from the outside shell of the suit.
- 2. Inspect all areas of the suit for visible signs of damage or degradation. Also inspect for rips, tears, or small punctures.
- 3. Close and open zipper several times to check for smooth operation. Lubricate the inside and outside of the front waterproof zipper with lubricant after each use.
- 4. Ensure the harness webbing is not worn or abraded and the safety clip functions smoothly.
- 5. To store suit, always ensure your Ice Commander is fully dry prior to stowing in its stowage bag.
- 6. Replace inside buoyant liner by attaching to inside zipper and buckles along the shell front, neck, wrists, and inside boot.
- 7. Lay your suit face down and roll feet first to the head area, fold in the arms and continue to roll suit lengthwise with the zipper on the outside. Replace in stowage bag and always ensure that it is accessible in case of emergency.
- 8. Never compress your Ice Commander by placing heavy objects on top of it, as this could result in loss of buoyancy to the inside foam liner.

REPAIRS & REPLACEMENTS

1. Damage to both the external shell and inner buoyant liner can be repaired by an authorized Mustang repair station. Major tears, rips or punctures and chemical or heat burns must be inspected and repaired by the manufacturer.

CLEANING INSTRUCTIONS

- 1. To clean the Ice Commander Immersion suit, begin by removing the inside foam liner from the outer shell.
- 2. Remove salt and stains using a mild detergent in cold or warm water. Avoid scrubbing the patches of reflective tape. Do not use volatile fluids such as petroleum distillates to clean the suit as they will break down the welded material.
- 3. The inside foam liner can be handwashed with mild detergent and rinsed thoroughly with clean water, then hung to dry. The outer shell component should be cleaned in the same manner, stains can be cleaned by gently rubbing with a soft brush.
- 4. Do not dry clean.

ZIPPER CARE INSTRUCTIONS

- 1. Clean the zipper of any heavy deposits of mud, sand, salt or foreign substances using warm soapy water. Rinse, and let dry.
- 2. Apply a recommended lubricant to the outer elements of the zipper only.
- 3. Open and close the zipper TWICE, then store the unit with the zipper OPEN
- 4. A suit that is used daily requires steps 1 to 3 to be done on a weekly basis, as a minimum, paying close attention to more frequent cleaning of the zipper as required

Recommended Zipper Lubricants: Zip Tech by McNett, Ortlieb