

OPERATING AND MAINTENANCE INSTRUCTIONS

BATTERY INSTALLATION – Gently unclip the latch and open the battery door at end of body. Install batteries, observing proper polarity. Press the door closed, beginning with the front and then snapping the rear latch closed.

NOTE: Some batteries emit hydrogen gas. This gas can create an explosion potential in sealed devices if not vented or removed. The Roam is equipped with a platinum catalyst to remove this gas. When replacing the batteries, visually inspect the LED module for broken or missing catalyst. If the catalyst appears to be damaged, (you may notice gray particles in the battery compartment), or the light has flooded, replace the catalyst before using.


WARNING: • Use alkaline AA batteries. • Never mix fresh and used batteries, different battery brands or chemistry types • Always remove drained batteries immediately. • Remove batteries during long periods of storage. • Improper installation of the batteries will damage the light and void the warranty.

O-Ring – Occasionally clean and lightly lubricate the O-Ring and lens cap threads. Use only silicone grease, never use aerosol spray lubricants. Certain aerosol sprays can cause damage and void warranty. To avoid water leakage, do not over tighten the lens cap.

MAINTENANCE – As with all equipment, Roam should be rinsed with fresh water after contact with salt water. Operate any moving parts while rinsing with water to prevent salt build-up.

USA - INTERNATIONAL LIMITED THREE YEAR WARRANTY

WARRANTY – Princeton Tec warrants this product to be free from defects in workmanship and materials under normal use for three years. This warranty covers all of the component parts of the product except batteries. This warranty does not cover deterioration due to normal wear or damage due to misuse, alteration, negligence, accidents, or unauthorized repair. Princeton Tec will repair or replace parts which are defective in workmanship or materials.



Your authorized Princeton Tec Dealer and Princeton Tec are the only facilities authorized to repair the product. After (3) unsuccessful attempts (within the warranty period) to repair the product, you have the right to elect replacement of the product or a refund of the purchase price less allowance for use of the product. **NO INCIDENTAL OR CONSEQUENTIAL DAMAGES ARE INCLUDED IN THIS WARRANTY.** (Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.) This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Princeton Tec reserves the right to change product specifications without notice.

RETURN POLICY

If your light fails to operate, follow these simple steps: 1) Check batteries. Replace if necessary. 2) Contact Princeton Tec customer service at 800-257-9080 to request an RMA number and mailing address to send your light for repair or replacement. Return your light without batteries. No warranties will be accepted without an RMA number. Postage due and freight collect items will not be accepted.

Princeton Tec
PO Box 8057,
Trenton, NJ 08650
Phone: 609-298-9331
Fax: 609-298-9601
© 2015 Princeton Tec

