


EXPLANATION OF GRAPHIC SYMBOLS:



The lightning flash with arrowhead within a triangle is intended to tell the user that parts inside the product are a risk of electric shock.




The exclamation point within a triangle is intended to tell the user that important operating and servicing instructions are in the papers with the appliance.

WARNING : TO PREVENT FIRE OR ELECTRIC SHOCK
HAZARD, DO NOT EXPOSE THIS PRODUCT
TO RAIN OR MOISTURE.




VA-100

AUDIO/VIDEO DISTRIBUTION BOX



OPERATING INSTRUCTION


1. BOX FUNCTIONS VIEW:



ITEM	FUNCTION
1.	VIDEO INPUT JACK
2.	AUDIO RIGHT INPUT JACK
3.	AUDIO LEFT INPUT JACK
4.	DC INPUT
5.	VIDEO OUTPUT JACK
6.	AUDIO RIGHT OUTPUT JACK
7.	AUDIO LEFT OUTPUT JACK

2. OPERATION PROCEDURE

- 1) Plug the DC Power cord into the AUDIO/VIDEO DISTRIBUTION DC 12V JACK + — — —
- 2) Insert the DC Power cord's other end into your vehicles cigarette lighter.
- 3) To receive VIDEO Signals from a VCR or a camcorder, connect the VIDEO component's VIDEO outputs to the jack using shielded VIDEO cables with phone connectors. See the component's instruction manual for more information about connecting it to a TV monitor.



(AUDIO/VIDEO DISTRIBUTER BOX)