

GETTING STARTED

Be sure to turn off your boat, ATV, vehicle, stereo, or amplifier before installation. Please read all instructions before beginning. For questions, email support@aquaticav.com or use chat with our Support Team with the Aquatic AV App (support available Mon-Fri, 8 AM - 5 PM PST).

Contents

When first unpacking your new speaker, please check first that the package contains all the items below. If something is missing, contact the store where you purchased the product.

- One (1) pair of 6.5" Speakers
- Grill
- Four (4) mounting screws
- Four (4) stainless steel speed clips
- Quick Start Guide
- Warranty information
- Template

Tools Needed


- Electric drill
- Drill bit (sizes will vary based on surface material)
- Phillips screwdriver / Allen wrench
- Appropriate saw or utility knife to cut the surface material
- 18 AWG or larger speaker wire
- 2.5 mm and 5.2 female speaker spade connectors (*recommended*)
- Wire strippers (*optional*)
- Crimping tool (*optional*)
- Electric tool (*optional*)
- Marine sealant (*optional*)

Additional Accessories (Sold Separately)

- The Aquatic AV RGB Controller (RG155R1)
- RGB 1 ft Extension Cable with DIN Connector (LC103)
- RGB 24 ft Extension Cable (LC107)
- RGB Y-Splitter (CB100)

NOTE: For customized installations, additional tools and materials may be needed. Please visit an authorized Aquatic AV dealer before doing customized installations.

DIMENSIONS



INSTALLATION

Mounting The Speakers

1. Please choose a mounting location with the following mounting considerations in mind.

NOTICE

During the installation of the Speaker, make sure to mount the speaker on a vertical surface. If mounted on a horizontal surface, water can be let in and deposit around the Speaker. This can harm the Speaker as time passes.

Make sure to turn off any power connection to the source unit, amplifier, or speakers during the installation process. Also check that the wires and connections are isolated from each other, not touching any surface. Otherwise, it can cause a short circuit, which may permanently damage the equipment and void the Product Warranty.


2. Route the speaker wires (and LED wires, if applicable) from the source to the speaker location with good clearance for the wires.

Considerations While Wiring Your Speakers

- Speaker wires are not included with the speakers. You should use 18 AWG or larger speaker wires to connect the speakers to the stereo
- The leads on the speakers are terminated using male spade connectors. You should use female spade connectors (Not Included) to connect the speaker wire to the speaker leads for better connection

| SPEAKER WIRE COLOR | SPEAKER WIRE POLARITY | SPADE CONNECTOR SIZE |
|-------------------------|-----------------------|----------------------|
| WHITE | POSITIVE (+) | 0.2" (5.20 MM) |
| WHITE WITH BLACK STRIPE | NEGATIVE (-) | 0.11" (2.8 MM) |

3. Trim the template and make sure it fits in the selected location with enough depth and clearance
4. Using a drill bit appropriate for the mounting surface, drill a hole inside the dashed line on the template to prepare the mounting surface for cutting
5. Using a jigsaw or rotary tool, cut the mounting surface along the inside of the line on the template
6. Use a file and sandpaper to refine the size of the cutout if deemed necessary



NOTE: Do not over-tighten the screws, especially if the mounting surface is not flat. Bending the speaker frame can cause distortion.

PRODUCT REGISTRATION

Register your new Aquatic AV product in order to receive a 2-year warranty. You will need proof of purchase, such as a receipt, from an authorized dealer. Additionally, you will have to provide your contact information, the date and location of the purchase.

You can submit a Product Registration form at the Aquatic AV Support Center or through the Aquatic AV App. The app is available on the App Store for iOS devices and on the Play Store for Androids.



WARRANTY

Aquatic AV offers a limited warranty of our products on the following terms:

Length Of Warranty

2 years on audio systems, electronics, speakers, and accessories (receipt required).

Coverage

This warranty covers only the original purchaser of a Aquatic AV product purchased from an authorized Aquatic AV dealer in the United States. In order to receive service, the purchaser must provide Aquatic AV with a copy of the receipt stating the customer name, dealer name, product purchased and date of purchase.

Defective Products

Products found to be defective during the warranty period will be repaired or replaced (with a product deemed to be equivalent) at Aquatic AV's discretion.

What Is Not Covered

- Damage caused by accident, abuse, improper operations, theft.
- Any cost or expense related to the removal or reinstallation of product.
- Any product with the serial number or tamper labels defaced, altered, or removed.
- Subsequent damage to other components.
- Any product not purchased from an authorized Aquatic AV dealer.

Limit On Implied Warranties

Any implied warranties including warranties of fitness for use and merchantability are limited in duration to the period of the express warranty set forth above. Some states do not allow limitations on the length of an implied warranty, so this limitation may not apply. No person is authorized to assume for Aquatic AV any other liability in connection with the sale of the product.

How To Obtain Service

You must obtain a return material authorization number (RMA) to return any product to Aquatic AV. You are responsible for shipping charges of returned products to Aquatic AV.

AQUATIC AV

AQUATIC AV

282 KINNEY DRIVE
SAN JOSE, CA 95112, USA

E-MAIL: INFO@AQUATICAV.COM

US & CANADA: 1 877 579 2782

INTERNATIONAL: +1 408 559 1668

FAX: +1 408 559 0125

AQUATICAV.COM



**California Proposition
65 Warning**



WARNING: This product contains chemicals known to the State of California to cause cancer, and birth defects or other reproductive harm.

For more information: www.P65Warnings.ca.gov