

CONCENTRATED PRODUCT

Mix 1 part Teak Magic with 4 parts fresh water (1:4)

TEAK MAGIC

TWO-PART CLEANER AND BRIGHTENER

PART

CLEANER



Teak Magic two-part cleaner is specially engineered to not destroy your teak or wood surface, instead it safely cleans and brings teak decks and wood furniture to their natural color and brightness. Its gel consistency makes it ideal for controlled application.

DIEC MARINE PRODUCTS

READ INSTRUCTIONS PRIOR TO USE KEEP OUT OF REACH OF CHILDREN 1 GALLON (3.78 L)



This product is not a marine pollutant and may be rinsed with fresh wash water into rivers, streams, and other waterways.

DITEC TEAK MAGIC PART 1

Recommended Usage:

For deep or heavy-duty cleaning of all teak surfaces, including large teak decks and teak furniture. Ideal for use in areas with sensitive surroundings (including finished metals). If product comes in contact with soft metals (aluminum, brass, etc) rinse off with water immediately.

Application:

Make sure to wear proper safety gear, including nitrile gloves. For best results apply **DITEC Teak**Magic Part 1 to a damp surface.

- In a clean bucket, mix one part Teak Magic
 Part 1 with four parts fresh water (1:4). Spread
 product completely and evenly onto the
 surface using a foam brush, deck brush or
 polypropylene scrub pad.
- Allow Part 1 to dwell on the surface for 3-5 minutes.
- Using a medium polypropylene scrub pad, make sure to scrub the teak with and against the wood grain with medium pressure to loosen dirt or contaminant particles.
- 4. Be sure to thoroughly rinse dirt and product off the teak with fresh water, including areas like cleats or scuppers where dirty water/product may flow and puddle up. Then apply Teak Magic Part 2 (Brightener).

DITEC believes that the environment is our most precious asset, and we must take personal responsibility for how we affect it. We develop products that are unsurpassed in quality and performance, and meet or exceed the highest environmental regulatory standards in the world. This product may be safely discharged into rivers, streams, oceans and other waterways.



First Aid

INHALATION: Remove to fresh air, if symptoms persist, seek medical attention.

EYES: Flush with water for at least 15 minutes while holding eyelids open. Call a physician if irritation persists. If worn, remove contacts after first 5 minutes.

SKIN: Remove contaminated clothing. Wash exposed area with soap and water for at least 15 minutes. Launder clothes before reuse. Call a physician if rash or other symptoms develop.

INGESTION: If ingested, may cause loose stools. Drink plenty (2-3 glasses) of water and immediately consult a physician. Do not induce vomiting.



WARNING: May cause skin or eye irritation.

DITEC Marine Products, LLC W229 N2512 Duplainville Rd. Waukesha, WI 53186 USA Tel: 1-800-572-4390 ditecmarineproducts.com





*Non regulated according to MARPOL guidelines



REV 07/25



CONCENTRATED PRODUCT

Mix 1 part Teak Magic with 4 parts fresh water (1:4)

TEAK MAGIC

TWO-PART CLEANER AND BRIGHTENER

PART

2

BRIGHTENER



Teak Magic two-part cleaner is specially engineered to not destroy your teak or wood surface, instead it safely cleans and brings teak decks and wood furniture to their natural color and brightness. Its gel consistency makes it ideal for controlled application.

DIEC MARINE PRODUCTS

READ INSTRUCTIONS PRIOR TO USE KEEP OUT OF REACH OF CHILDREN 1 GALLON (3.78 L)



This product is not a marine pollutant and may be rinsed with fresh wash water into rivers, streams, and other waterways.

DITEC TEAK MAGIC PART 2

Recommended Usage:

For deep or heavy-duty cleaning of all teak surfaces, including large teak decks and teak furniture. Ideal for use in areas with sensitive surroundings (including finished metals). If product comes in contact with soft metals (aluminum, brass, etc) rinse off with water immediately.

Application:

Make sure to wear proper safety gear, including nitrile gloves.

- After thoroughly and completely rinsing off Teak Magic Part 1, remove excess puddles of water. Surface should be damp. In a clean bucket, mix one part Teak Magic Part 2 with four parts fresh water (1:4).
- Apply Part 2 to the damp surface. Spread product completely and evenly onto the surface using a foam brush, soft bristle deck brush or medium polypropylene scrub pad. There is no need to scrub the product in this step, let the product do the work.
- Allow Part 2 to dwell on the surface for 3-5 minutes.
- 4. After teak has brightened, rinse the surface thoroughly with fresh water, including areas like cleats or scuppers where dirty water/ product may flow and puddle up, to ensure the product is entirely off the surface. Remove excess water and allow teak to dry.

When teak is completely dry and cool, apply **DiTEC Triton 2.0** to protect (for up to 3-6 months) against dirt, UV, rain, salt, oil, and food and beverage stains.

DITEC believes that the environment is our most precious asset, and we must take personal responsibility for how we affect it. We develop products that are unsurpassed in quality and performance, and meet or exceed the highest environmental regulatory standards in the world. This product may be safely discharged into rivers, streams, oceans and other waterways.



First Aid

INHALATION: Remove to fresh air, if symptoms persist, seek medical attention.

EYES: Flush with water for at least 15 minutes while holding eyelids open. Call a physician if irritation persists. If worn, remove contacts after first 5 minutes.

SKIN: Remove contaminated clothing. Wash exposed area with soap and water for at least 15 minutes. Launder clothes before reuse. Call a physician if rash or other symptoms develop.

INGESTION: If ingested, may cause loose stools. Drink plenty (2-3 glasses) of water and immediately consult a physician. Do not induce vomiting.



WARNING: May cause skin or eye irritation.

DITEC Marine Products, LLC W229 N2512 Duplainville Rd. Waukesha, WI 53186 USA Tel: 1-800-572-4390 ditecmarineproducts.com





*Non regulated according to MARPOL guidelines



REV 07/25