



# ACTIVE HEADING WIRELESS FOOT BUTTON INSTRUCTIONS

DESCRIPTION

#8 x 1 1/4" Pan Head Sheet Metal Screw

Active Heading Wireless Foot Button

### **TOOLS:**

#### **INCLUDED HARDWARE:**

ITEM #

AVG-MH-SC-0274

SA-0034-AH

LABEL

А

В

QTY.

3

1


- Fine-tip Marker
- Electric Drill
- 7/64" Drill Bit
- #2 Phillips Screwdriver




Check the area beneath where the Foot Button will be mounted to ensure there are no hoses, wires, lines, tanks, or other sensitive components.

- **STEP 1** Choose a flat surface with adequate space to mount the Foot Button.
- **STEP 2** Mark mounting holes using a fine-tip marker.
- STEP 3 Drill mounting holes using a 7/64" Drill Bit.
- STEP 4 Install (3) Screws (A) and tighten snug using a #2 Phillips Screwdriver.

**IMPORTANT!** If installing to gel-coat, follow the drilling procedure in **Appendix A** in the Installation & Owner's Guide to ensure you do not crack or chip the gel-coat.





(Anchor Mode Foot Button Depicted)

### **USING THE ACTIVE HEADING WIRELESS FOOT BUTTON**

This foot button is used to toggle **Active Heading** on or off. The **Active Heading Foot Button** must be tapped **twice** to turn it on. It is deactivated by a single tap.





## ACTIVE HEADING WIRELESS FOOT BUTTON INSTRUCTIONS

## PAIRING PROCEDURE


Tap the 🔄 and 😥 on the Hybrid Remote at the same time. **This will open a 6 second pairing window** (The MOVE will make a consistent tone and the 3 LEDs on the Head Unit will intermittently flash **TEAL**). Then, press the Foot Button you are pairing. The Navigation Head will beep twice, indicating pairing is complete.


NOTICE: To open the pairing window, the Hybrid Remote must be within 2ft. of the Move.

#### **BATTERY REPLACEMENT**

**IMPORTANT!** When replacing battery, ensure the Foot Button and the surrounding area is as dry as possible to avoid any moisture intrusion.

- STEP 1 Insert a small, Flat Head Screwdriver into the notch to pry it apart.
- STEP 2 Remove the battery from the holder on the Circuit Board and replace with any CR2032 3V Lithium Coin Battery.
- STEP 3 Lay the Circuit Board flush in the Bottom Housing, ensuring it lays flat.
- STEP 4 Lay the Foam Pad on the Circuit Board.
- STEP 5 Insert the Plastic Disc into the Membrane. FIG 1
- STEP 6 Install the Membrane to the Bottom Housing so the Tab goes into the Notch on the Bottom Housing. Make sure the Plastic Disc does not fall out. FIG 2
- STEP 7 Reinstall the Top Housing so it snaps into place and there is no gap between it and the Bottom Housing. FIG 3











## ACTIVE HEADING WIRELESS FOOT BUTTON INSTRUCTIONS

#### General Statement (for all devices)

Warning: Changes or modifications to this device not expressly approved by JL Marine Systems, Inc. could void the user's authority to operate the equipment.

#### **FCC Specific Statement**

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

FCC Part 15.19 Warning Statement – (Required for all Part 15 devices) THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST NOT ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

FCC Part 15.21 Warning Statement – NOTE: THE GRANTEE IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

#### FCC/ISED RF Exposure

ENGLISH: This equipment complies with radiation exposure limits set forth for an uncontrolled environment. This equipment is in direct contact with the body of the user under normal operating conditions. The transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

FRENCH: Cet équipment est conforme aux limites d'exposition aux radiations dans un environment non controle. Cet équipment est en contact direct avec le corps de l'utilisateur dans des conditions de fonctionnement normales. Cet émetteur ne doit pas être co-localisées ou opérant en conjunction avec tout autre antenne ou transmetteur.

ENGLISH: This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must not accept any interference, including interference that may cause undesired operation of the device.

FRENCH: Le présent est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de license. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

MODEL NUMBER	FCC ID:	IC:
MV-AC-FS-HEAD	A7FEA205	11454A-EA205

