


# Mini Alarm Wiring Diagram



Note: Posi-Tap™ connectors, terminal block, or other connection type can be used to connect the wiring cable to sensor wires.

## Installation Instructions:

1. Connect black alarm wire to Relay Control 1 (purple) or Relay Control 2 (white) on the wiring cable.
2. Connected red audible alarm wire to +12VDC

Note: The output(s) on the Siren 3 Series Devices have a maximum draw of 1 amp. If you are connecting any devices to the same output as the horn that exceed this limit, you will also need to use an appropriate DC Relay (maximum of 10 amps)

Product SKU: SM-ACC3-ALRM-MINI