


Parts Index


* Not to scale

Patented & Pats. Pend.
rammount.com/ip



A

Tray Assembly



B

(x4) Long Arms



C

(x4) Short Arms




D

(x4) Angled Brackets



E

(x2) Foam Pads




F

(x4) Screws
#8-32 x 3/4"



G

(x4) Nylock Nuts
#8-32



H


(x4) Screws
#10-24 x 3/4"




I

(x4) Nylock Nuts
#10-24

1 Place laptop on tray with lid open. Using a screwdriver, loosen and rotate the rear posts to seat properly against the back of your laptop.



2 Select **(B)** or **(C) Arms** depending on what is most appropriate for the thickness of your laptop. Slide **(D) Angled brackets** into selected arms until you hear a satisfying "click".



RMR-INS-2347




Safety Precaution


Do not install this product near or over an airbag deployment area or in a location that obstructs the driver's vision or interferes with vehicle operation. Electronic devices attached to this product are not to be used while vehicle is in motion. National Products, Inc. does not assume responsibility or liability for any such personal injury, death, or property damage.

- 3 Connect selected arms from Step 2 to the sides of the **(A) Tray** using **(F) Screws** and **(G) Nuts**. Select holes on the sides of the tray that will not block any necessary port or drive access.

Position the arms so that the **(D) Angled Brackets** rest flush against laptop keyboard.



- 4 Connect **(A) Tray** to ball (not included) using **(H) Screws** and **(I) Nuts**.



RMR-INS-2347



Safety Precaution

Do not install this product near or over an airbag deployment area or in a location that obstructs the driver's vision or interferes with vehicle operation. Electronic devices attached to this product are not to be used while vehicle is in motion. National Products, Inc. does not assume responsibility or liability for any such personal injury, death, or property damage.

Specifications

Placement

Passenger side on the floor, in front seat.

Seat Configuration

Bucket

Drilling Required

None - uses existing seat bolts.

Construction/Finish


Steel/Black powder coat

Dimensions

(A) 18" (B) 6.75" (C) 2.31"
(Hole Center) 16"


Pole or Pedestal

Purchased separately



Important Note

Utilizes existing vehicle hardware. Plastic trim may be re-installed once the RAM® No-Drill™ base has been secured into vehicle.



RMR-INS-VB-187



Safety Precaution


Do not install this product near or over an airbag deployment area or in a location that obstructs the driver's vision or interferes with vehicle operation. National Products, Inc does not assume responsibility or liability for any such personal injury, death or property damage.

Installation Instructions

If installing this base with a RAM® Tele-Pole™ assembly, attach the lower female pole prior to installing the RAM® No-Drill™ base. The carriage bolts should come up through the bottom with the rubber caps on the top side covering the nuts once attachment is complete.

- 1 Move the passenger side seat to its most forward position and only loosen the two seat track bolts using a 13MM socket wrench. Note that it is not necessary to completely remove ANY vehicle hardware during this installation. Just loosen it.
- 2 Move the passenger seat to its rearmost position and remove the plastic trim covers over the seat frame leg bolts. These pieces may be replaced after installation. A small flat head screw driver works well to remove these without damaging them.
- 3 Loosen the front seat leg bolts using a 13MM socket wrench. Using an extension with the socket wrench is recommended. Though not necessary, it is suggested that you use a T-20 torx bit and loosen the two plastic trim covers to allow the base to more easily slip underneath both the trim and the seat frame legs.
- 4 Gently lift the front of the seat to allow clearance for the base between the legs and the vehicle floor board. Slide the no drill base under the trim and seat frame leg. Push the base all the way under so the back side of the slots touches the seat leg bolts. Re-tighten the seat leg bolts. If you loosened the torx screws in the plastic trim, very gently re-tighten these screws as well.
- 5 Reinstall the plastic covers over the seat frame leg bolts. Move the seat forward once again and fully tighten the rear seat track bolts previously loosened.

Note that once installed, this base will slightly lessen the amount of forward travel available to the passenger side seat. Accessing the glove box is still possible once system is installed.



RMR-INS-VB-187





Safety Precaution

Do not install this product near or over an airbag deployment area or in a location that obstructs the driver's vision or interferes with vehicle operation. National Products, Inc does not assume responsibility or liability for any such personal injury, death or property damage.

Parts Index

Not to scale



Safety Precaution

Do not install this product near or over an airbag deployment area or in a location that obstructs the driver's vision or interferes with vehicle operation. National Products, Inc does not assume responsibility or liability for any such personal injury, death or property damage.

RMR-INS-VB-TP