

POWER-POLE
ONETM
DUAL ANCHOR PUMP



ONE PUMP REMOTE
QUICK START GUIDE

Powered by



C-MONSTER
CONTROL SYSTEM **2.0**

REMOTE PARTS



LABEL	DESCRIPTION	QTY.
A	One Pump Remote	1
B	One Pump Remote Cradle	1
C	#8 1/2" Screw	2
D	Adhesive Strip	1
E	Lanyard	1



CRADLE INSTALLATION

For full remote instructions, consult the **One Pump Installation & Owner's Guide**

NOTE: The remote cradle (B) may also be installed using the supplied adhesive strip (D).

1. Locate a suitable area with a flat surface to mount the remote cradle (B).
2. Mark the upper hole location with a fine point marker and drill a pilot hole using a 7/64" drill bit.
3. Place the remote cradle (B) in the desired location and install one of the screws (C) through the top hole in the remote cradle (B).
4. Repeat Steps 2-3 for the lower hole and mounting screw (C).

CRADLE INSTALLATION

WARNING!

Before installing the self tapping screws, inspect the area beneath the mounting surface to ensure that the screws will not cause any damage.



PAIRING & PROGRAMMING

IMPORTANT! New remotes must be paired to the HPU.

1. Press and hold the **PROGRAM** button on the top of the HPU for **3 seconds** (**LED** will turn **GREEN**/HPU will beep).
2. Press the **UP** button on the controller for one second. When paired, the **GREEN LED** will turn off then flash steadily. **HPU** will beep.



STOWING & DEPLOYING

STANDARD OPERATION

Press and hold either the Up or Down Button. The anchor will only continue to move as long as the button is pressed.

AUTO MODE

Double tap either the Up or Down Button. The anchors will automatically run until stowed or deployed.

NOTE:

Auto mode can be changed to a single tap via the Power-Pole App.



SPEED CONTROL

The remote has 3 speed settings: slow, medium, and fast.

Tap  to toggle anchor speed.

The LED lights will indicate speed setting.



Slow



Medium



Fast

BATTERY REPLACEMENT

IMPORTANT!

Ensure the switch and the surrounding area is as dry as possible to avoid any moisture intrusion before changing the battery in the controller.

1. Insert a small flathead screwdriver into the bottom of the remote to pry it apart.
2. Remove the battery from the holder on the circuit board and replace with a CR2032 3V lithium coin battery.
3. Re-assemble the remote, ensuring that the membrane is seated properly in the front shell prior to installing the cover and the front and rear shells fully snap into place.



BATTERY REPLACEMENT

COMPLIANCE STATEMENTS

FCC Part 15.19 Warning Statement

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

FCC Part 15.21 Warning Statement

NOTE: THE GRANTEE IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

IC RSS-GEN, Sec 7.1.3 Warning Statement

ENGLISH: This device complies with Industry Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

FRENCH: Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

IC RSS-GEN, Sec 7.1.2 Warning Statement

ENGLISH: Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry

COMPLIANCE STATEMENTS

Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

FRENCH: Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

IC RSS-102, Sec 2.6 Warning Statements

ENGLISH: The applicant is responsible for providing proper instructions to the user of the radio device, and any usage restrictions, including limits of exposure durations. The user manual shall provide installation and operation instructions, as well as any special usage conditions, to ensure compliance with SAR and/or RF field strength limits. For instance, compliance distance shall be clearly stated in the user manual.

FRENCH: Le mode d'emploi des appareils destinés à l'utilisation contrôlée doit aussi inclure des informations sur les caractéristiques de fonctionnement de l'appareil; les instructions de fonctionnement pour assurer la conformité avec SAR et / ou les limites d'intensité de champ RF; informations sur l'installation et l'exploitation d'accessoires pour assurer le respect des SAR et / ou les limites d'intensité de champ RF; et les coordonnées où l'utilisateur peut obtenir des informations sur l'exposition canadienne de radiofréquences et la conformité. Autres renseignements connexes peuvent également être inclus.

Detailed instructions can be found at www.power-pole.com/manuals

Need Help? Contact our Customer Service Team at

1 + 813.689.9932



9010 Palm River Road Tampa, Florida 33619

Phone 1+ (813) 689-9932 | Fax 1+(813) 689-8883

www.power-pole.com



©2024 All rights reserved. Power-Pole Shallow Water Anchor