

SWIFT. SILENT. SECURE.

UNIVERSAL ALUMINUM BRACKET INSTRUCTIONS


NOTE: This adapter bracket can be mounted on either port or starboard.

Hardware

- A. (1) Adapter plate
- **B.** (1) Brace
- C. (1) Backer plate
- **D.** (4) 4 & 1/4" x 1/2" Transom bolts
- **E.** (4) 1/2" Lock nuts
- F. (8) 1/2" Heavy thunder washers
- **G.** (4) 3/8" x 2" Power-Pole anchor bolts
- H. (4) 3/8" Neo-bond washer
- I. (4) 3/8" Heavy thunder washer
- **J.** (4) 3/8" Lock nuts
- **K.** (4) 5/16" x 1 & 3/4" Micro anchor bolts
- L. (4) 5/16" Heavy thunder washer
- M.(4) 5/16" Lock nuts

Installation Tools:

- 9/16" & 3/4" Socket with ratchet
- 9/16" & 3/4" Wrench
- 1/2" Steel drill bit with drill
- 1/4" Allen wrench (Micro install only)
- 1/2" Socket with ratchet (Micro install only)
- 1/2" Wrench (Micro install only)
- Pencil



ALUMINUM BOAT ADAPTER PLATE

Installation Instructions:

- STEP 1. Place bracket (A) up against the outer lip of rub rail as illustrated and mark the hole locations. FIG. 1
- **STEP 2**. Drill the marked hole locations with a 1/2" steel drill bit.
- **STEP 3**. Place heavy thunder washers (**F**) onto bolts (**D**).
- STEP 4. With adapter plate (A) in position install two transom bracket bolts (D). FIG. 1 Section 1.1
- STEP 5. Place backer plate (C) onto transom bolts (D) followed by a thunder washer (F) and thread lock nut (E) onto each bolt and tighten. FIG. 1 Section 1.2




Figure 1

ALUMINUM BOAT ADAPTER PLATE

- **STEP 6.** Place brace (**B**) on top of adapter plate (**A**) aligning holes and push the two remaining transom bolts (**D**) through brace (**B**), adapter plate (**A**) and backer plate (**C**). **FIG. 2 Sections 2.1& 2.2**
- STEP 7. Place thunder washer (F) onto remaining bolts (D) and thread lock nuts (E) on and tighten. FIG. 2 Section 2.2






Figure 2

ALUMINUM BOAT ADAPTER PLATE

STEP 8. Install the bolts and hardware as illustrated for your Power-Pole or Micro anchor and tighten. **FIG. 3 & 4**





Need help? Contact our Technical Support Team at 1 + 813.689.9932 Option 2